

User manual

# Table of Contents


	3
	3
	4
	4
	4 5
Radar coverage	5 7
Installation examples and use cases	
Get started	
Get started	
Open the device's web interface	
Open the device's web interface	
Secure passwords	
Verify that no one has tampered with the device software	
Secure passwords 12 Verify that no one has tampered with the device software 13 Web interface overview 13	
Configure vour device	
Configure your device         14           Optimize the device for speed measurement and license plate capture         14	
Basic settings	
Adjust the image	
View and record video	
Additional radar settings 23	
Set up rules for events 26	
Audio	2
The web interface	
Status	
Video	
Radar	
Analytics	
Audio	
Recordings	
Apps	
System	
Maintenance       68         Learn more       69	
Learn more 65 Long-distance connections 65	
Remote focus and zoom	
Privacy masks	
Overlays	
Streaming and storage	
Cybersecurity	
Cybersecurity	
Product overview	
LED indicators	5
SD card slot	5
Buttons	6
Connectors	
Clean your device	
Troubleshooting	
Reset to factory default settings 80	
AXIS OS options	
Check the current AXIS OS version	
Upgrade AXIS OS	
Technical issues, clues, and solutions	
Performance considerations	
Contact support 82	2

## Solution overview

## Solution overview

A radar-video fusion camera is a visual camera with a fully integrated radar module. As such, this camera can use the radar to measure the speed of approaching or departing vehicles, and the video to capture license plates.

Use AXIS Q1686-DLE with an optional license plate capture application, like AXIS License Plate Verifier, or with a third-party solution, to process the images and speed provided by the camera.



AXIS Q1686-DLE is mounted on a pole on the side of a highway, and measures the speed and captures the license plates of approaching vehicles.

## Radar-video fusion

Each technology in AXIS Q1686-DLE – radar, video, and optional license plate capture software – generates metadata on its own. The metadata includes information like speed, object class, direction, and license plate information. What's special about this device is that it fuses the metadata, which means it connects the speed and license plate of the same vehicle.

#### Note

AXIS Q1686-DLE produces the fused metadata, which needs to be processed by a video management software (VMS) or other platform. The VMS requests the metadata through the RTSP metadata stream and can use the data to trigger actions or log statistics.

The fused metadata is not available in the web interface of the device.

# Installation

# Installation

This video shows an example of how to install a radar-video fusion camera.

For complete instructions on all installation scenarios as well as important safety information, see the installation guide on axis.com/products/axis-q1686-dle/support



Note: The optical unit of the camera in the video is not identical with the one in AXIS Q1686-DLE.

### Preview mode

Preview mode is ideal for installers when fine tuning the camera view during the installation. No login is required to access the camera view in preview mode. It is available only in factory defaulted state for a limited time from powering up the device.



This video demonstrates how to use preview mode.

## Considerations

### Where to install the product

Mount the product appropriately to get the best video and radar coverage. Consider the following when you mount a radar-video fusion camera that is going to be used for license plate capture:

### Center or side mounted


You can mount the camera on a gantry above the road, or on a sturdy pole on the side of a road. The ability to capture license plates and measure the speed of vehicles is affected by factors like the mounting height of the device, its position, the zoom of the camera, and the speed of approaching or departing vehicles. For more information about possible mounting scenarios, see .

#### Environment

Environmental aspects can affect the performance of the video and the radar. Direct sunlight can distort the image and affect the camera's ability to capture license plates. Solid and metal objects, such as road signs, trees or large bushes, can affect the radar by

## Installation

creating blind spots (radar shadow) behind the object. Metal objects in the field of detection, such as containers or trams, can cause reflections that affect the radar's ability to perform classifications, which can lead to ghost tracks and false alarms in the radar stream.



- 1 Actual detection
- 2 Reflected detection (ghost track)

#### Radar coexistence

If you mount more than eight radars or radar-video fusion cameras operating on the 60 GHz frequency band close together, they may interfere with each other, which can affect the radar's performance.

### License plate capture software

AXIS Q1686-DLE doesn't include any license plate capture software. However, the device is built on an open platform, which makes it possible to use the device with third-party solutions on the edge or server side.

You can use AXIS Q1686-DLE with the edge application AXIS License Plate Verifier. The combination has been thoroughly tested and produces metadata that connects the speed and direction of a vehicle with its license plate. For recommendations on how to mount the device when you're going to use it with AXIS License Plate Verifier, see .

For information about third-party options for license plate capture, see *axis.com/support/tools/technology-partner-finder*. Contact your preferred supplier for recommendations on how to use the software.

### Radar coverage

The radar in AXIS Q1686-DLE has a horizontal field of detection of 95°. Its detection range depends on factors like the mounting height and tilt angle of the device, and the size and speed of moving vehicles. The detection range also depends on the radar profile.

There are two available profiles in this radar: road monitoring and area monitoring. The road monitoring profile is optimized for tracking vehicles moving at speeds up to 200 km/h (125 mph) while the area monitoring profile is optimized for tracking humans, vehicles and unknown objects moving at speeds up to 55 km/h (34 mph).

By default, the radar profile in AXIS Q1686-DLE is set to Road monitoring. For more information about the radar's detection range when used for road monitoring, see .

If you want to use AXIS Q1686-DLE for area monitoring instead, select the Area monitoring profile. For information about the radar's detection range when used for area monitoring, see .

#### Note

To change the radar profile, go to Radar > Settings > Detection.

#### Road detection range

The road monitoring profile in the radar is optimized for detection of vehicles and is recommended when you use the radar-video fusion camera for speed measurement and license plate capture. With the road monitoring profile, the radar provides a speed accuracy of +/-2 km/h (1.25 mph) when monitoring approaching or departing vehicles moving at up to 200 km/h (125 mph).

The mounting height of the radar-video fusion camera and the vehicle speed impacts the detection range of the radar. When mounted at an optimal installation height, the radar detects approaching and departing vehicles within the following ranges:

- 25-100 m (82-328 ft) for vehicles moving at 50 km/h (31 mph).
- 40-80 m (131-262 ft) for vehicles moving at 100 km/h (62 mph).

## Installation

• 50-70 m (164-230 ft) for vehicles moving at 200 km/h (125 mph).

#### Note

To minimize the risk of missed detections of vehicles travelling in high speeds, set up a scenario in the radar that triggers on the object types Vehicle and Unknown. For more information about how to set up a radar scenario, see .


### Area detection range

The detection range is the distance within which an object can be tracked and can trigger an alarm. It's measured from a near detection limit (how close to the device a detection can be made) to a far detection limit (how far from the device a detection can be made).

The area monitoring profile is optimized for human detection, however, it will also allow you to track vehicles and other objects moving at up to 55 km/h (34 mph) with a speed accuracy of +/- 2 km/h (1.25 mph).

When mounted at the optimal installation height, the detection ranges are:

- 5 60 m (16-200 ft) when detecting a human
- 5 90 m (16–300 ft) when detecting a vehicle



#### Note

- Enter the mounting height in the web interface when you calibrate the radar.
- The detection range is affected by the scene and the product's tilt angle.
- The detection range is affected by the moving object type and size.

The radar detection range was measured under these conditions:

- The range was measured along the ground.
- The object was a person with a height of 170 cm (5 ft 7 in).
- The person was walking straight in front of the radar.
- The values were measured when the person entered the detection zone.
- The radar sensitivity was set to Medium.

Mounting height	15° tilt	20° tilt	25° tilt	30° tilt	35° tilt	40° tilt	45° tilt
3.5 m	6.0-60+ m	5.0-60+ m	4.0-60+ m	4.0-60 m	4.0–55 m	4.0-40 m	4.0-30 m
(11 ft)	(19-196+ ft)	(16-196+ ft)	(13-196+ ft)	(13-196 ft)	(13– 180 ft)	(13-131 ft)	(13-98 ft)
4.5 m	6.0-60+ m	6.0-60+ m	5.0-60+ m	4.0-60+ m	4.0-60 m	4.0–45 m	4.0-40 m
(14 ft)	(19-196+ ft)	(19-196+ ft)	(16-196+ ft)	(13-96+ ft)	(13-196 ft)	(13–147 ft)	(13-131 ft)

# Installation

Mounting height	15° tilt	20° tilt	25° tilt	30° tilt	35° tilt	40° tilt	45° tilt
6 m	10-60+ m	9.0-60+ m	7.0-60+ m	6.0-60+ m	6.0-60 m	5.0-55 m	5.0-55 m
(19 ft)	(32-196+ ft)	(29-196+ ft)	(22-196+ ft)	(19-196+ ft)	(19-196 ft)	(16-180 ft)	(16-180 ft)
8 m	16-60 m	14–60 m	10-60 m	8.0-60+ m	8.0-60+ m	7.0-60 m	7.0-60 m
(26 ft)	(52-196 ft)	(45–196 ft)	(32-196 ft)	(26-196+ ft)	(26-196+ ft)	(22-196 ft)	(22-196 ft)
10 m	21-60 m	19–60 m	14-60 m	12-60+ m	10-60+ m	9.0–60 m	9.0-60 m
(32 ft)	(68-196 ft)	(62–196 ft)	(45-196 ft)	(39-196+ ft)	(32-196+ ft)	(29–196 ft)	(29-196 ft)
12 m	25-60 m	23–60 m	19-60 m	16-60+ m	13-60+ m	11–60 m	11-55 m
(39 ft)	(82-196 ft)	(75–196 ft)	(62-196 ft)	(52-196+ ft)	(42-196+ ft)	(36–196 ft)	(36-180 ft)

Note

- Setting the radar sensitivity to Low will decrease the detection range by 20% while setting it to High will increase the detection range by 20%.
- In installations where you expect small animals to appear outside the fusion zone, but still in the detection zone of the radar, you can minimize the false alarms by setting the radar sensitivity to Low. This will however reduce the detection range.


### Installation examples and use cases

### Installation examples

#### Center mounted


You can mount the radar-video fusion camera on a gantry above the road. This is the recommended placement if you want to measure the speed and capture license plates in two adjacent lanes.

Place the camera above the vehicles to view the license plates head on, and make sure to zoom in so that the lane, or lanes, where you intend to capture license plates cover the image.



The same type of installation is possible if you want to capture license plates and the speed of vehicles that drive away from the radar-video fusion camera, instead of driving towards it.


# Installation



#### Side mounted

You can mount the radar-video fusion camera on a sturdy pole on the side of the road. If you intend to capture license plates in two lanes in this type of installation, we recommend a lateral distance of max 7 m (23 ft) between the camera and the centre of the farthest lane on the road.

Make sure to zoom in so that the lane, or lanes, where you intend to capture license plates cover the image.



### Recommendations

- For recommendations about how to mount the device when using AXIS License Plate Verifier, see .
- For information about license plate capture in general, see the white paper "License plate capture" at *axis.com/learning/white-papers*.


### Road monitoring use cases

### Wrong-way detection

To capture the speed and license plates of vehicles driving in the wrong direction on a highway ramp, traffic control uses AXIS Q1686-DLE with AXIS License Plate Verifier installed.

## Installation


They mount the camera on a pole facing the ramp according to . For reliable detections, they set up a line crossing scenario in the radar pages of the device's web interface and configure it so that a vehicle must cross two virtual lines to trigger an alarm. In the radar scenario, they position the two lines across the ramp and specify the driving direction and speed the radar should trigger on.



With this configuration, the radar detects vehicles and their speed when driving in the wrong direction. At the same time, the camera can provide visual identification and capture the license plates of the vehicles. With this setup it's possible to create rules for events, for example to trigger a recording when the vehicle crosses the lines, or trigger external lights that can warn the driver. Additionally, the license plate information can be processed on the server side.

The same setup is possible for capturing rear license plates. The radar measures the speed of departing vehicles while the camera captures the rear license plates.

# Installation



For an example of how to create a rule that triggers a recording, see .

# Mounting recommendations

AXIS Q1686-DLE has been thoroughly tested with the application AXIS License Plate Verifier. The mounting recommendations in the following tables are based on the combined performance of the camera, radar and application.

The optimal distance for the device to capture license plates of vehicles travelling in high speeds is 40 m (131 ft). As seen in the tables, you can capture license plates closer or further away than 40 m (131 ft), but at slower speeds.

### Center mounted

This table shows the recommendations for a device that is mounted on a gantry above the road where there is no lateral distance between the camera and the road.

Mounting height	Tilt angle	Capture distance	Speed
6 m (19.7 ft)	13°	25 m (82 ft)	Up to 80 km/h (50 mph)
	9°	40 m (131 ft)	Up to 200 km/h (124 mph)
	7°	50 m (164 ft)	Up to 125 km/h (78 mph)
8 m (26.2 ft)	18°	25 m (82 ft)	Up to 80 km/h (50 mph)
	11°	40 m (131 ft)	Up to 160 km/h (99 mph)
	9°	50 m (164 ft)	Up to 104 km/h (65 mph)

Definitions of the table parameters are available in .

# Installation

#### Side mounted

This table shows the recommendations for a device that is mounted on a pole on the side of the road where the lateral distance from the camera to the centre of the farthest lane on the road is max 7 m (23 ft).

Mounting height	Tilt angle	Pan angle	Capture distance	Speed
6 m (19.7 ft)	13°	16°	25 m (82 ft)	Up to 50 km/h (31 mph)
	9°	10°	40 m (131 ft)	Up to 140 km/h (87 mph)
	7°	8°	50 m (164 ft)	Up to 125 km/h (78 mph)
8 m (26.2 ft)	18°	16°	25 m (82 ft)	Up to 50 km/h (31 mph)
	11°	10°	40 m (131 ft)	Up to 140 km/h (87 mph)
	9°	8°	50 m (164 ft)	Up to 104 km/h (65 mph)

Definitions of the table parameters are available in .

For information about how to configure the device so it can measure the speed of passing vehicles and capture license plates, see .

### Definitions

- Mounting height: The distance from the ground up to the optics in the device.
- Tilt angle: The downward tilt angle, or vertical angle, of the device.
- **Pan angle**: The horizontal angle of the device when it's side mounted and directed at the point on the road where you expect to capture license plates.
- Capture distance: The distance from the device to the point on the road where you expect to capture license plates
- Speed: The maximum speed at which the device can capture license plates and at the same time measure the speed of passing vehicles.

## Get started

## Get started

### Find the device on the network

To find Axis devices on the network and assign them IP addresses in Windows<sup>®</sup>, use AXIS IP Utility or AXIS Device Manager. Both applications are free and can be downloaded from *axis.com/support*.

For more information about how to find and assign IP addresses, go to How to assign an IP address and access your device.

### **Browser support**

You can use the device with the following browsers:

	Chrome <sup>TM</sup>	Firefox®	Edge™	Safari®
Windows®	recommended	recommended	$\checkmark$	
macOS®	recommended	recommended	$\checkmark$	V
Linux®	recommended	recommended	$\checkmark$	
Other operating systems	$\checkmark$	$\checkmark$	$\checkmark$	√*

\*To use AXIS OS web interface with iOS 15 or iPadOS 15, go to **Settings > Safari > Advanced > Experimental Features** and disable NSURLSession Websocket.

### Open the device's web interface

1. Open a browser and type the IP address or host name of the Axis device.

If you do not know the IP address, use AXIS IP Utility or AXIS Device Manager to find the device on the network.

2. Type the username and password. If you access the device for the first time, you must create an administrator account. See .

For descriptions of all the controls and options in the device's web interface, see .

### Create an administrator account

The first time you log in to your device, you must create an administrator account.

- 1. Enter a username.
- 2. Enter a password. See .
- 3. Re-enter the password.
- 4. Accept the license agreement.
- 5. Click Add account.

### Important

The device has no default account. If you lose the password for your administrator account, you must reset the device. See .

### Secure passwords

#### Important

Axis devices send the initially set password in clear text over the network. To protect your device after the first login, set up a secure and encrypted HTTPS connection and then change the password.

# Get started

The device password is the primary protection for your data and services. Axis devices do not impose a password policy as they may be used in various types of installations.

To protect your data we strongly recommend that you:

- Use a password with at least 8 characters, preferably created by a password generator.
- Don't expose the password.
- Change the password at a recurring interval, at least once a year.

## Verify that no one has tampered with the device software

To make sure that the device has its original AXIS OS, or to take full control of the device after a security attack:

1. Reset to factory default settings. See .

After the reset, secure boot guarantees the state of the device.

2. Configure and install the device.

## Web interface overview

This video gives you an overview of the device's web interface.



Axis device web interface

# Configure your device

# Configure your device

## Optimize the device for speed measurement and license plate capture

This radar-video fusion camera is factory-calibrated so that the camera and radar module are perfectly aligned.

Note

Do not move or remove the lens, optical unit or radar module since this will undo the calibration and alignment.

To set up the device for vehicle detection and speed measurement, and to optimize the image for license plate capture, follow these steps:

- 1. 2. 3. 4. 5.
- 6.
- 7.

### Set the mounting height in the radar

The mounting height is measured from the ground up to the optics in the device and should be as accurate as possible to detect and measure the speed of passing vehicles correctly. For scenes with uneven surfaces, add the value that represents the average height in the scene.

- 1. Go to Radar > Settings > General.
- 2. Set the height under Mounting height.

### Aim and tilt the device

Aim and tilt the device towards the area where you intend to capture license plates.

#### Note

This procedure requires physical access to the device.

1. If you're using the device with AXIS License Plate Verifier, check the tables in for tilt angle recommendations based on mounting height of the device, intended capture distance, and vehicle speed.

If you're using a third-party license plate capture solution, contact your supplier for recommendations.

- 2. Loosen the screw in the wall mount.
- 3. Aim the camera at the road where you intend to capture license plates.
- 4. Tilt the device according to the recommendations.
- 5. Validate the position of the device, see for instructions.

### Validate the mounting height and tilt

#### Note

This procedure requires physical access to the device.

# Configure your device

To validate the position of the device, add an augmented overlays in the camera's live view. The overlay shows a projection of the radar through a grid, including the distance from the device to the road. This will help you check that the radar detects vehicles correctly at the intended capture distance.

- 1. Go to Video > Image.
- 2. Click in the live view to access the device's onscreen controls.
- 3. Expand Predefined controls.
- 4. Turn on Augmented overlay (radar).
- 5. Click Toggle augmented overlay.
- 6. In the camera's live view, check that the distance to the road is correct in the projected grid.
- 7. If necessary, re-measure the mounting height and adjust the settings, or adjust the tilt angle, and check again.
- 8. When you have validated the position of the device, tighten the screws in the wall mount.

#### Note

Turn off the augmented overlay when you're done with the validation.

### Add lanes in the radar

Add lanes in the radar that correspond to the lanes on the road you are monitoring. The lanes in the radar improves the tracking and performance when detecting vehicles and the speed they're travelling in.

- 1. Go to Radar > Settings > Object Visualization.
- 2. Set Trail lifetime to 1 hour.


This shows the trail of passing vehicles on the road, which makes it easier to position the lanes.

- 3. Go to Radar > Lanes.
- 4. Click + Add lane.
- 5. By default, the name of the first lane will be Lane 1. Expand it to edit the name.
- 6. Click on the lane in the radar view and use the mouse to move and shape it to cover the desired part of the radar view or reference map. One lane in the radar should correspond to one lane on the road you are monitoring.
- 7. Check that the trail of the passing vehicles stays within the lane, or lanes, you have added.
- 8. Click Lanes enabled to activate the lanes you have added.

Repeat the steps to add an additional lane. We recommend that you add a maximum of two lanes.

Example:

## Configure your device



The camera view is illustrated on the left side, and the radar view with two added lanes in yellow on the right. The passing car is shown as a white track in the radar view, followed by a trail.

To change the unit of measurement in the radar grid, go to System > Regional settings.

### Add exclude zones

Exclude zones are areas in which moving objects will be ignored. Add exclude zones to ignore, for example, swaying foliage on the side of a road. You could also add exclude zones to ignore ghost tracks caused by radar-reflective materials, for example a metal fence.

Add an exclude zone:

- 1. Go to Radar > Exclude zones.
- 2. Click Add exclude zone.

Use the mouse to move and shape the zone so that it covers the desired part of the radar view or reference map.

### Optimize the image for license plate capture

- 1. In the device's web interface, go to Video > Installation > Traffic camera installation assistant.
- 2. Select the surveillance mode License plate capture.
- 3. Click Next.
- 4. Under Capture settings, add the following information:
  - **Camera height**: the distance between the camera and the ground.
  - Road distance: the lateral distance between the camera and the middle of the lane that you are going to monitor.
  - **Typical car speed**: the typical speed of the approaching or departing vehicles.

Note

Turn on Accelerometer to calculate the car distance automatically.

- Car distance: the distance between the camera and the approaching or departing vehicles.
- 5. Click Next in the traffic camera installation assistant.
- 6. The assistant provides a scene profile and a max shutter value for your installation. To save these settings, click **Apply** settings.
- 7. In the live view, zoom in so that the view covers the lane or lanes that you want to monitor. See for more information.

# Configure your device

8. To verify the settings, record a few vehicles passing by and look at the license plates in the recording. See for more information.

### Set up a license plate capture solution

Set up a license plate capture solution that can process the images provided by the camera. For more information, see .

#### **AXIS License Plate Verifier**

If you're going to use AXIS Q1686-DLE with AXIS License Plate Verifier, see AXIS License Plate Verifier user manual for information about how to set up the application.

If you intend to capture license plates in two lanes, we recommend that you create one area of interest for each lane in the application. For instructions, see Adjust the area of interest in AXIS License Plate Verifier user manual.

To validate that AXIS License Plate Verifier captures the license plates correctly, turn on license plate overlays in the web interface of AXIS Q1686-DLE. For more information, see .

### **Basic settings**

Set the capture mode

- 1. Go to Video > Installation > Capture mode.
- 2. Click Change.
- 3. Select a capture mode and click Save and restart.

See also .

Set the power line frequency

- 1. Go to Video > Installation > Power line frequency.
- 2. Click Change.
- 3. Select a power line frequency and click Save and restart.

## Adjust the image

This section includes instructions about configuring your device. If you want to learn more about how certain features work, go to .

### Level the camera

To adjust the view in relation to a reference area or an object, use the level grid in combination with a mechanical adjustment of the camera.

1. Go to Video > Image > and click



2. Click to show the level grid.

3. Adjust the camera mechanically until the position of the reference area or the object is aligned with the level grid.

### Adjust the zoom and focus

To adjust the zoom:

1. Go to Video > Installation and adjust the zoom slider.

# Configure your device

To adjust the focus:

- 1. Click to show the autofocus area.
- 2. Adjust the autofocus area to cover the part of the image that you want to be in focus.

If you don't select an autofocus area, the camera focuses on the entire scene. For traffic scenes where you intend to capture license plates, we recommend that you focus on the lines in the centre of the road.

- 3. Click Autofocus.
- 4. To fine tune the focus, adjust the focus slider.

### Select scene profile

A scene profile is a set of predefined image appearance settings including color level, brightness, sharpness, contrast and local contrast. Scene profiles are preconfigured in the product for quick setup to a specific scenario, for example **Forensic** which is optimized for surveillance conditions. For a description of each available setting, see .

You can select a scene profile during the initial setup of the camera. You can also select or change scene profile later.

- 1. Go to Video > Image > Appearance.
- 2. Go to Scene profile and select a profile.

### Reduce image processing time with low latency mode

You can optimize the image processing time of your live stream by turning on low latency mode. The latency in your live stream is reduced to a minimum. When you use low latency mode, the image quality is lower than usual.

- 1. Go to System > Plain config.
- 2. Select ImageSource from the drop-down list.
- 3. Go to ImageSource/IO/Sensor > Low latency mode and select On.
- 4. Click Save.

### Select exposure mode

To improve image quality for specific surveillance scenes, use exposure modes. Exposure modes lets you control aperture, shutter speed, and gain. Go to Video > Image > Exposure and select between the following exposure modes:

- For most use cases, select Automatic exposure.
- For environments with certain artificial lighting, for example fluorescent lighting, select Flicker-free.

Select the same frequency as the power line frequency.

• For environments with certain artificial light and bright light, for example outdoors with fluorescent lighting at night and sun during daytime, select Flicker-reduced.

Select the same frequency as the power line frequency.

• To lock the current exposure settings, select Hold current.

### Benefit from IR light in low-light conditions by using night mode

Your camera uses visible light to deliver color images during the day. But as the visible light diminishes, color images become less bright and clear. If you switch to night mode when this happens, the camera uses both visible and near-infrared light to deliver bright and detailed black-and-white images instead. You can set the camera to switch to night mode automatically.

# Configure your device

- 1. Go to Video > Image > Day-night mode, and make sure that the IR-cut filter is set to Auto.
- 2. To use the built-in IR light when the camera is in night mode, turn on Allow illumination and Synchronize illumination.

### **Optimize IR illumination**

Depending on the installation environment and the conditions around the camera, for example external light sources in the scene, you can sometimes improve the image quality if you manually adjust the intensity of the LEDs. If you have problems with reflections from the LEDs, you can try to reduce the intensity.

- 1. Go to Video > Image > Day-night mode.
- 2. Turn on Allow illumination.
- 3. Click **G** in the live view and select **Manual**.
- 4. Adjust the intensity.

#### Reduce noise in low-light conditions

To reduce noise in low-light conditions, you can adjust one or more of the following settings:

- Adjust the trade-off between noise and motion blur. Go to Video > Image > Exposure and move the Blur-noise trade-off slider toward Low noise.
- Set the exposure mode to automatic.

#### Note

A high max shutter value can result in motion blur.

• To slow down the shutter speed, set max shutter to the highest possible value.

#### Note

When you reduce the max gain, the image can become darker.

- Set the max gain to a lower value.
- If possible, move the slider under Aperture toward Open.
- Reduce sharpness in the image, under Video > Image > Appearance.

### Reduce motion blur in low-light conditions

To reduce motion blur in low-light conditions, adjust one or more of the following settings in Video > Image > Exposure:

• Move the Blur-noise trade-off slider toward Low motion blur.

#### Note

When you increase the gain, image noise also increases.

• Set Max shutter to a shorter time, and Max gain to a higher value.

If you still have problems with motion blur:

- Increase the light level in the scene.
- Mount the camera so that objects move toward it or away from it rather than sideways.

# Configure your device

### Maximize the details in an image

#### Important

If you maximize the details in an image, the bitrate will probably increase and you might get a reduced frame rate.

- Make sure to select the capture mode that has the highest resolution.
- Go to Video > Stream > General and set the compression as low as possible.
- Below the live view image, click and in Video format, select MJPEG.
- Go to Video > Stream > Zipstream and select Off.

### Handle scenes with strong backlight

Dynamic range is the difference in light levels in an image. In some cases the difference between the darkest and the brightest areas can be significant. The result is often an image where either the dark or the bright areas are visible. Wide dynamic range (WDR) makes both dark and bright areas of the image visible.

- 1. Go to Video > Image > Wide dynamic range.
- 2. Use the Local contrast slider to adjust the amount of WDR.
- 3. Use the Tone mapping slider to adjust the amount of WDR.
- 4. If you still have problems, go to Exposure and adjust the Exposure zone to cover the area of interest.

Find out more about WDR and how to use it at *axis.com/web-articles/wdr*.

### Stabilize a shaky image with image stabilization

Image stabilization is suitable in environments where the product is mounted in an exposed location where vibrations can occur, for example, due to wind or passing traffic.

The feature makes the image smoother, steadier, and less blurry. It also reduces the file size of the compressed image and lowers the bitrate of the video stream.

#### Note

When you turn on image stabilization, the image is slightly cropped, which lowers the maximum resolution.

- 1. Go to Video > Installation > Image correction.
- 2. Turn on Image stabilization.

#### Hide parts of the image with privacy masks

You can create one or several privacy masks to hide parts of the image.

1. Go to Video > Privacy masks.

2. Click +

- 3. Click the new mask and type a name.
- 4. Adjust the size and placement of the privacy mask according to your needs.
- 5. To change the color for all privacy masks, click **Privacy masks** and select a color.

See also

## Configure your device

### Show an image overlay

You can add an image as an overlay in the video stream.

- 1. Go to Video > Overlays.
- 2. Select Image and click
- 3. Click Images.
- 4. Drag and drop an image.
- 5. Click Upload.
- 6. Click Manage overlay.
- 7. Select the image and a position. You can also drag the overlay image in the live view to change the position.

### Show a text overlay

You can add a text field as an overlay in the video stream. This is useful for example when you want to display the date, time or a company name in the video stream.

- 1. Go to Video > Overlays.
- 2. Select Text and click
- 3. Type the text you want to display in the video stream.
- 4. Select a position. You can also drag the overlay text field in the live view to change the position.

#### Add street names and compass direction to the image

#### Note


The street name and compass direction will be visible on all video streams and recordings.

- 1. Go to Apps.
- 2. Select axis-orientationaid.
- 3. Click Open.
- 4. To add a street name, click Add text and modify the text to fit the street.
- 5. To add a compass, click Add compass and modify the compass to fit the image.

### Show license plate overlays

License plate overlays are available with the optional application AXIS License Plate Verifier.

1. Go to Video > Image.



- 3. Expand Predefined controls.
- 4. Turn on License plate overlay.
- 5. Click Show overlay.

## Configure your device

6. To move the overlay, click Move overlay.

### View and record video

This section includes instructions about configuring your device. To learn more about how streaming and storage works, go to .

### Reduce bandwidth and storage

#### Important

Reducing the bandwidth can lead to loss of detail in the image.

1. Go to Video > Stream.



2. Click **Q** in the live view.

- 3. Select Video format H.264.
- 4. Go to Video > Stream > General and increase Compression.
- 5. Go to Video > Stream > Zipstream and do one or more of the following:

#### Note

The Zipstream settings are used for both H.264 and H.265.

- Select the Zipstream Strength that you want to use. \_
- Turn on Optimize for storage. This can only be used if the video management software supports B-frames.
- Turn on Dynamic FPS.
- Turn on Dynamic GOP and set a high Upper limit GOP length value.

#### Note

Most web browsers don't support H.265 decoding and because of this the device doesn't support it in its web interface. Instead you can use a video management system or application that supports H.265 decoding.

### Set up network storage

To store recordings on the network, you need to set up your network storage.

- 1. Go to System > Storage.
- 2. Click + Add network storage under Network storage.
- 3. Type the IP address of the host server.
- 4. Type the name of the shared location on the host server under Network share.
- 5. Type the username and password.
- 6. Select the SMB version or leave it on Auto.
- 7. Select Add share without testing if you experience temporary connection issues, or if the share is not yet configured.
- 8. Click Add.

# Configure your device

### Record and watch video

Record video directly from the camera

- 1. Go to Video > Image.
- 2. To start a recording, click

If you haven't set up any storage, click and the set up network storage, see

3. To stop recording, click again.

#### Watch video

- 1. Go to Recordings.
- 2. Click for your recording in the list.

### Verify that no one has tampered with the video

With signed video, you can make sure that no one has tampered with the video recorded by the camera.

- 1. Go to Video > Stream > General and turn on Signed video.
- 2. Use AXIS Camera Station (5.46 or later) or another compatible video management software to record video. For instructions, see the AXIS Camera Station user manual.
- 3. Export the recorded video.
- 4. Use AXIS File Player to play the video. *Download AXIS File Player*.

indicates that no one has tampered with the video.

#### Note

To get more information about the video, right-click the video and select Show digital signature.

## Additional radar settings

### Upload a reference map

The default live view of the radar will show the radar coverage and any detected movement, and you can add detection zones and rules right away. To make it easier to see where objects are moving, upload a reference map, for example a ground plan or an aerial photo, that shows the area covered by the radar.

# Configure your device




Image requirements:

- Supported file formats are jpeg and png.
- The orientation is not important, since the radar coverage shape will move to adapt to the image during calibration.

Upload the reference map and calibrate it so that the actual radar coverage fits the position, direction and scale of the map.

- 1. Go to Radar > Map calibration.
- 2. Upload your reference map and follow the setup assistant.

### Add scenarios

A scenario is a combination of triggering conditions and detection settings, which you can use to create rules in the event system. Add scenarios if you want to create different rules for different parts of the scene.

Add a scenario:

- 1. Go to Radar > Scenarios.
- 2. Click Add scenario.
- 3. Type the name of the scenario.
- 4. Select if you want to trigger on objects moving in an area or on objects crossing one, or two, lines.

Trigger on objects moving in an area:

- 1. Select Movement in area.
- 2. Click Next.

## Configure your device

3. Select the type of zone that should be included in the scenario.

Use the mouse to move and shape the zone so that it covers the desired part of the radar image or reference map.

- 4. Click Next.
- 5. Add detection settings.
  - 5.1 Add seconds until trigger after under Ignore short-lived objects.
  - 5.2 Select which object type to trigger on under Trigger on object type.
  - 5.3 Add a range for the speed limit under Speed limit.
- 6. Click Next.
- 7. Set the minimum duration of the alarm under Minimum trigger duration.
- 8. Click Save.

Trigger on objects crossing a line:

- 1. Select Line crossing.
- 2. Click Next.
- 3. Position the line in the scene.

Use the mouse to move and shape the line.

- 4. To change the detection direction, turn on Change direction.
- 5. Click Next.
- 6. Add detection settings.
  - 6.1 Add seconds until trigger after under Ignore short-lived objects.
  - 6.2 Select which object type to trigger on under Trigger on object type.
  - 6.3 Add a range for the speed limit under **Speed limit**.
- 7. Click Next.
- 8. Set the minimum duration of the alarm under Minimum trigger duration.

The default value is set to 2 seconds. If you want the scenario to trigger every time an object crosses the line, lower the duration to 0 seconds.

9. Click Save.

Trigger on objects crossing two lines:

- 1. Select Line crossing.
- 2. Click Next.
- 3. To make the object cross two lines for the alarm to trigger, turn on Require crossing of two lines.
- 4. Position the lines in the scene.

Use the mouse to move and shape the line.

- 5. To change the detection direction, turn on Change direction.
- 6. Click Next.

## Configure your device

- 7. Add detection settings.
  - 7.1 Set the time limit between crossing the first and the second line under Max time between crossings.
  - 7.2 Select which object type to trigger on under Trigger on object type.
  - 7.3 Add a range for the speed limit under Speed limit.
- 8. Click Next.
- 9. Set the minimum duration of the alarm under Minimum trigger duration.

The default value is set to 2 seconds. If you want the scenario to trigger every time an object has crossed the two lines, lower the duration to 0 seconds.

10. Click Save.

#### Show a text overlay with the tilt angle of the radar

You can add an overlay in the radar's live view that shows the tilt angle of the radar. This is helpful during installation, or whenever you need to know the tilt angle of the device.

#### Note

The tilt angle overlay shows "90" when the device is horizontal. If the overlay shows "75", the tilt angle of the radar is 15° below the horizon.

- 1. Go to Radar > Overlays.
- 2. Select Text and click
- 3. Type **#op**.

You can also click Modifier and select #op from the list.

4. Select a position. You can also drag the overlay field in the live view to change the position.

### Set up rules for events

To learn more, check out our guide Get started with rules for events.

#### Trigger an action

- 1. Go to System > Events and add a rule. The rule defines when the device will perform certain actions. You can set up rules as scheduled, recurring, or manually triggered.
- 2. Enter a Name.
- 3. Select the **Condition** that must be met to trigger the action. If you specify more than one condition for the rule, all of the conditions must be met to trigger the action.
- 4. Select which Action the device should perform when the conditions are met.

#### Note

If you make changes to an active rule, the rule must be turned on again for the changes to take effect.

#### Note

If you change the definition of a stream profile that is used in a rule, then you need to restart all the rules that use that stream profile.

## Configure your device

#### Save power when no motion is detected

This example explains how to turn on power saving mode when no motion is detected in the scene.

#### Note

When you turn on power saving mode, the IR illumination range is reduced.

Make sure that AXIS Object Analytics is running:

- 1. Go to Apps > AXIS Object Analytics.
- 2. Start the application if it is not already running.
- 3. Make sure you have set up the application according to your needs.

#### Create a rule:

- 1. Go to System > Events and add a rule.
- 2. Type a name for the rule.
- 3. In the list of conditions, under Application, select Object Analytics.
- 4. Select Invert this condition.
- 5. In the list of actions, under Power saving mode, select Use power saving mode while the rule is active.
- 6. Click Save.

### Record video when the camera detects an object

This example explains how to set up the camera to start recording to the SD card when the camera detects an object. The recording will include five seconds before detection and one minute after detection ends.

Before you start:

• Make sure you have an SD card installed.

Make sure that AXIS Object Analytics is running:

- 1. Go to Apps > AXIS Object Analytics.
- 2. Start the application if it is not already running.
- 3. Make sure you have set up the application according to your needs.

#### Create a rule:

- 1. Go to System > Events and add a rule.
- 2. Type a name for the rule.
- 3. In the list of conditions, under Application, select Object Analytics.
- 4. In the list of actions, under Recordings, select Record video while the rule is active.
- 5. In the list of storage options, select SD\_DISK.
- 6. Select a camera and a stream profile.
- 7. Set the prebuffer time to 5 seconds.
- 8. Set the postbuffer time to 1 minute.
- 9. Click Save.

## Configure your device

#### Show a text overlay in the video stream when the device detects an object

This example explains how to display the text "Motion detected" when the device detects an object.

Make sure that AXIS Object Analytics is running:

- 1. Go to Apps > AXIS Object Analytics.
- 2. Start the application if it is not already running.
- 3. Make sure you have set up the application according to your needs.

Add the overlay text:

- 1. Go to Video > Overlays.
- 2. Under **Overlays**, select **Text** and click
- 3. Enter #D in the text field.
- 4. Choose text size and appearance.
- 5. To position the text overlay, click 🛡 and select an option.

#### Create a rule:

- 1. Go to System > Events and add a rule.
- 2. Type a name for the rule.
- 3. In the list of conditions, under Application, select Object Analytics.
- 4. In the list of actions, under Overlay text, select Use overlay text.
- 5. Select a video channel.
- 6. In Text, type "Motion detected".
- 7. Set the duration.
- 8. Click Save.

#### Note

If you update the overlay text it will be automatically updated on all video streams dynamically.

### Provide visual indication of an ongoing event

You have the option to connect the AXIS I/O Indication LED to your network camera. This LED can be configured to turn on whenever certain events occur in the camera. For example, to let people know that video recording is in progress.

#### Required hardware

- AXIS I/O Indication LED
- An Axis network video camera

#### Note

For instructions on how to connect the AXIS I/O Indication LED, see the installation guide provided with the product.

The following example shows how to configure a rule that turns on the AXIS I/O Indication LED to indicate that camera is recording.

1. Go to System > Accessories > I/O ports.

## Configure your device

2. For the port that you connected the AXIS I/O Indication LED to, click to set the direction to **Output**, and click

to set the normal state to Circuit open.

- 3. Go to System > Events.
- 4. Create a new rule.
- 5. Select the **Condition** that must be met to trigger the camera to start recording. It can, for example, be a time schedule or motion detection.
- 6. In the list of actions, select **Record video**. Select a storage space. Select a stream profile or create a new. Also set the **Prebuffer** and **Postbuffer** as required.
- 7. Save the rule.
- 8. Create a second rule and select the same **Condition** as in the first rule.
- 9. In the list of actions, select Toggle I/O while the rule is active, and then select the port the AXIS I/O Indication LED is connected to. Set the state to Active.
- 10. Save the rule.

Other scenarios where AXIS I/O Indication LED can be used are for example:

- Configure the LED to turn on when the camera starts, to indicate the presence of the camera. Select **System ready** as a condition.
- Configure the LED to turn on when live stream is active to indicate that a person or a program is accessing a stream from the camera. Select Live stream accessed as a condition.

#### Record video when the camera detects impact

Shock detection allows the camera to detect tampering caused by vibrations or shock. Vibrations due to the environment or to an object can trigger an action depending on the shock sensitivity range, which can be set from 0 to 100. In this scenario, someone is throwing rocks at the camera after hours and you would like to get a video clip of the event.

Turn on shock detection:

- 1. Go to System > Detectors > Shock detection.
- 2. Turn on shock detection, and adjust the shock sensitivity.

#### Create a rule:

- 3. Go to System > Events > Rules and add a rule.
- 4. Type a name for the rule.
- 5. In the list of conditions, under Device status, select Shock detected.
- 6. Click + to add a second condition.
- 7. In the list of conditions, under Scheduled and recurring, select Schedule.
- 8. In the list of schedules, select After hours .
- 9. In the list of actions, under Recordings, select Record video while the rule is active.
- 10. Select where to save the recordings.
- 11. Select a Camera.
- 12. Set the prebuffer time to 5 seconds.

## Configure your device

- 13. Set the postbuffer time to 50 seconds.
- 14. Click Save.

#### Trigger an alarm if someone opens the housing

This example explains how to trigger an alarm if someone opens the housing.

#### Add a recipient:

- 1. Go to System > Events > Recipients and click Add recipient.
- 2. Type a name for the recipient.
- 3. Select Email.
- 4. Type an email address to send the email to.
- 5. The camera doesn't have it's own email server, so it will need to log into another email server to be able to send mails. Fill in the rest of the information according to your email provider.
- 6. To send a test email, click Test.
- 7. Click Save.

### Create a rule:

- 8. Go to System > Events > Rules and add a rule.
- 9. Type a name for the rule.
- 10. In the list of conditions, select Casing open.
- 11. In the list of actions, select Send notification to email.
- 12. Select a recipient from the list.
- 13. Type a subject and a message for the email.
- 14. Click Save.

### Send an email automatically if someone spray paints the lens

Activate the tampering detection:

- 1. Go to System > Detectors > Camera tampering.
- 2. Set a value for Trigger delay. The value indicates the time that must pass before an email is sent.
- 3. Turn on Trigger on dark images to detect if the lens is sprayed, covered, or rendered severely out of focus.

Add an email recipient:

- 4. Go to System > Events > Recipients and add a recipient.
- 5. Type a name for the recipient.
- 6. Select Email.
- 7. Type an email address to send the email to.
- 8. The camera doesn't have it's own email server, so it has to log into another email server to send mails. Fill in the rest of the information according to your email provider.
- 9. To send a test email, click Test.

## Configure your device

10. Click Save.

#### Create a rule:

- 11. Go to System > Events > Rules and add a rule.
- 12. Type a name for the rule.
- 13. In the list of conditions, under Video, select Tampering.
- 14. In the list of actions, under Notifications, select Send notification to email and then select the recipient from the list.
- 15. Type a subject and a message for the email.
- 16. Click Save.

### Use MQTT to send radar data

Use the radar-video fusion camera with the application AXIS Speed Monitor to collect radar data for detected objects and send it over MQTT.

This example explains how to set up an MQTT client in the device where you have installed AXIS Speed Monitor, and how to create a condition that will publish the radar data collected in AXIS Speed Monitor as a payload to an MQTT broker.

Before you start:

• Install AXIS Speed Monitor in your radar-video fusion camera, or install it in a camera that you connect to the radar in the radar-video fusion camera.

For more information, see AXIS Speed Monitor user manual.

• Set up an MQTT broker and get the broker's IP address, username and password.

Learn more about MQTT and MQTT brokers in AXIS OS Knowledge Base.

Set up the MQTT client in the web interface of the device where you have installed AXIS Speed Monitor:

- 1. Go to System > MQTT > MQTT client > Broker and enter the following information:
  - Host: The broker IP address
  - Client ID: The ID of the device
  - Protocol: The protocol the broker is set to
  - **Port**: The port number used by the broker
  - The broker Username and Password
- 2. Click Save and Connect.

Create a condition that publishes the radar data as a payload to the MQTT broker:

- 3. Go to System > MQTT > MQTT publication and click + Add condition.
- 4. In the list of conditions, under Application, select Speed Monitor: Track exited zone.

The device will now be able to send information about the radar tracks for every moving object that exits a scenario. Every object will have its own radar track parameters, for example rmd\_zone\_name, tracking\_id, and trigger\_count. You can find the full list of parameters in AXIS Speed Monitor user manual.

#### Trigger a recording if a vehicle drives in the wrong direction

This example explains how to trigger a recording and record video to an SD card if the radar detects that a vehicle drives in the wrong direction.

## Configure your device

Before you start:

• Make sure you have installed an SD card.

Add a scenario in the radar:

- 1. Go to Radar > Scenarios.
- 2. Click + Add scenario.
- 3. Type the name of the scenario.
- 4. Select Line crossing.
- 5. Click Next.
- 6. To make the object cross two lines for the alarm to trigger, turn on Require crossing of two lines.
- 7. Position the lines in the scene.

Use the mouse to move and shape them.

- 8. To change the detection direction, turn on Change direction.
- 9. Click Next.
- 10. Add detection settings.
  - 10.1 Set the time limit between crossing the first and the second line under Max time between crossings.
  - 10.2 Select that you want to trigger on vehicles under Trigger on object type.
  - 10.3 Add a range for the speed limit under Speed limit.
- 11. Click Next.
- 12. Set the minimum duration of the alarm under Minimum trigger duration.

The default value is set to 2 seconds. If you want the scenario to trigger every time an object has crossed the two lines, lower the duration to 0 seconds.

13. Click Save.

Create a rule that triggers a recording:

- 1. Go to System > Events and add a rule
- 2. Type a name for the rule.
- 3. In the list of conditions, under Radar motion, select the scenario you just created.
- 4. In the list of actions, under Recordings, select Record video while the rule is active.
- 5. In the list of storage options, select SD\_DISK.
- 6. Select Camera 1.
- 7. Set the prebuffer time to 5 seconds.
- 8. Set the postbuffer to 30 seconds.
- 9. Click Save.

## Configure your device

### Audio

### Add audio to your recording

Turn on audio:

- 1. Go to Video > Stream > Audio and include audio.
- 2. If the device has more than one input source, select the correct one in **Source**.
- 3. Go to Audio > Device settings and turn on the correct input source.
- 4. If you make any changes to the input source, click **Apply changes**.

Edit the stream profile that is used for the recording:

- 5. Go to **System > Stream profiles** and select the stream profile.
- 6. Select Include audio and turn it on.
- 7. Click Save.

### Connect to a network speaker

Network speaker pairing allows you to use a compatible Axis network speaker as if it is connected directly to the camera. Once paired, the speaker acts as an audio out device where you can play audio clips and transmit sound through the camera.

#### Important

For this feature to work with a video management software (VMS), you must first pair the camera with the network speaker, then add the camera to your VMS.

#### Pair camera with network speaker

- 1. Go to System > Edge-to-edge > Pairing.
- 2. Type the network speaker's IP address, username and password.
- 3. Select Speaker pairing.
- 4. Click Connect. A confirmation message appears.


## The web interface

## The web interface

To reach the device's web interface, type the device's IP address in a web browser.

#### Note

Support for the features and settings described in this section varies between devices. This icon  $\Psi$  indicates that the feature or setting is only available in some devices.



### Status

#### Device info

Shows the device information, including AXIS OS version and serial number.

Upgrade AXIS OS: Upgrade the software on your device. Takes you to the Maintenance page where you can do the upgrade.

#### Time sync status

Shows NTP synchronization information, including if the device is in sync with an NTP server and the time remaining until the next sync.

NTP settings: View and update the NTP settings. Takes you to the Date and time page where you can change the NTP settings.

#### Security

Shows what kind of access to the device that is active, what encryption protocols are in use, and if unsigned apps are allowed. Recommendations to the settings are based on the AXIS OS Hardening Guide.

Hardening guide: Link to AXIS OS Hardening guide where you can learn more about cybersecurity on Axis devices and best practices.

#### Connected clients

Shows the number of connections and connected clients.

View details: View and update the list of connected clients. The list shows IP address, protocol, port, state, and PID/process of each connection.

# The web interface

### Ongoing recordings


Shows ongoing recordings and their designated storage space.

**Recordings:** View ongoing and filtered recordings and their source. For more information, see Shows the storage space where the recording is saved.

Video

Click to play the live video stream. Click to freeze the live video stream. Click to take a snapshot of the live video stream. The file is saved in the 'Downloads' folder on your computer. The image file name is [snapshot_YYYY_MM_DD_HH_MM_SS.jpg]. The size of the snapshot depends on the compression that the specific web-browser engine where the snapshot is received applies, therefore, the snapshot size may vary from the actual compression setting that is
configured in the device. $\land$ $(i)$ Click to show I/O output ports. Use the switch to open or close the circuit of a port, for example, to test external devices. $(i)$ Click to manually turn on or turn off the IR illumination. $(i)$ Click to
manually turn on or turn off the white light. • Predefined controls: Turn on to use the available onscreen controls.
Custom controls: Click Add custom control to add an onscreen control.
Starts the washer. When the sequence starts, the camera moves to the configured position to receive the wash spray. When the whole wash sequence is completed, the camera returns to its previous position. This icon is only visible when the washer
is connected and configured. Starts the wiper. Click and select a preset position to go to that preset position in the live view. Or, click Setup to go to the preset position page. Adds or removes a focus recall area.
recall area and the camera enters that area in the live view, the camera recalls the previously saved focus. It's enough to cover half
of the area for the camera to recall the focus. Click to select a guard tour, then click <b>Start</b> to play the guard tour. Or, click <b>Setup</b> to go to the guard tours page. Click to manually turn on the heater for a selected period of time. Click to start a continuous recording of the live video stream. Click again to stop the recording. If a recording is ongoing, it will
resume automatically after a reboot. Click to show the storage that is configured for the device. To configure the storage,
you need to be logged in as an administrator. Click to access more settings: • Video format: Select the encoding format to use in the live view.
<ul> <li>Autoplay: Turn on to autoplay a muted video stream whenever you open the device in a new session.</li> <li>Client stream information: Turn on to show dynamic information about the video stream used by the browser that shows the live video stream. The bitrate information differs from the information shown in a text overlay, because of different information sources. The bitrate in the client stream information is the bitrate of the last second, and it comes from the encoding driver of the device. The bitrate in the overlay is the average bitrate of the last 5 seconds, and it comes from the browser. Both values cover only the raw video stream and not the additional bandwidth generated when it's transported over the network through UDP/TCP/HTTP.</li> <li>Adaptive stream: Turn on to adapt the image resolution to the viewing client's actual display resolution, to improve the user experience and help prevent a possible overload of the client's hardware. The adaptive stream is only</li> </ul>

# The web interface



### Installation

: A capture mode is a preset configuration that defines how the camera captures images. When you Capture mode change the capture mode, it can affect many other settings, such as view areas and privacy masks. Mounting position The orientation of the image can change depending on how you mount the camera. Power line frequency: To minimize image flicker, select the frequency your region uses. The American regions usually use 60 Hz. The rest of the world mostly uses 50 Hz. If you're not sure of your region's power line frequency, check with the local authorities. Zoom: Use the slider to adjust the zoom level.Focus: Use the slider to manually set the focus.AF: Click to make the camera focus on the selected area. If you don't select an autofocus area, the camera focuses on the entire scene.Autofocus area: Click to show the autofocus area. This area should include the area of interest. Reset focus: Click to make the focus return to its original position.

In cold environments, it can take several minutes for the zoom and focus to become available.

#### Image correction

#### Important

Note

We recommend you not to use multiple image correction features at the same time, since it can lead to performance issues. : Turn on to get a straighter image if it suffers from barrel distortion. Barrel distortion Barrel distortion correction (BDC) is a lens effect that makes the image appear curved and bent outwards. The condition is seen more clearly when the image is : Use the slider to adjust the correction level. A lower level means that the image width is kept at the zoomed out.Crop expense of image height and resolution. A higher level means that image height and resolution are kept at the expense of • : Use the slider to adjust the correction level. Pucker means that the image width is image width.Remove distortion kept at the expense of image height and resolution. Bloat means that image height and resolution are kept at the expense of image width.Image stabilization : Turn on to get a smoother and steadier image with less blur. We recommend that you use image stabilization in environments where the device is mounted in an exposed location and subject to vibrations due to, for example, wind or passing traffic.Focal length : Use the slider to adjust the focal length. A higher value leads to higher magnification and a narrower angle of view, while a lower value leads to a lower magnification and a wider angle of 36

# The web interface


view.Stabilizer margin : Use the slider to adjust the size of the stabilizer margin, which determines the level of vibration to stabilize. If the product is mounted in an environment with a lot of vibration, move the slider towards Max. As a result, a smaller scene is captured. If the environment has less vibration, move the slider towards Min.Straighten image : Turn on and use the slider to straighten the image horizontally by rotating and cropping it digitally. The functionality is useful when it's not possible to mount the camera exactly level. Ideally, straighten the image during installation. : Click to show a supporting grid in the image. : Click to hide the grid.
The image before and after it has been straightened.

Traffic camera installation assistance

Surveillan	ce mode
	License plate capture: Select if you're setting up the camera for license plate capture. Traffic overview: Select if you're setting up the camera for road monitoring. ettings
•	Camera height: Enter the distance between the camera and the ground. Road distance: Enter the distance between the camera and the middle of the lane you are monitoring. Typical car speed: Enter the typical car speed. Accelerometer: Turn on to automatically get the distance between the camera and the cars on the road. Car distance: Enter the distance between the camera and the cars on the road. n overview
	ew shows the camera's current position, and indicates if the position is according to recommendations. Red values the recommendations.
•	Vertical angle: The recommended vertical angle, or tilt angle, is between 0 and 29°. Horizontal angle: The recommended horizontal angle, or pan angle, is between 0 and 29°. Roll angle: The recommended roll angle is between 0 and 24°. Car distance: The calculated distance between the moving vehicles and the camera. tings
An overvie	w of the suggested Max shutter and Scene profile settings based on your configuration.
•	Apply settings: Click to activate the configuration. Your device reloads and updates the scene profile.

Appearance

# The web interface



Wide dynamic range

# The web interface

WDR : Turn on to make both bright and dark areas of the image visible.Local contrast : Use the slider to adjust the
contrast of the image. A higher value makes the contrast higher between dark and light areas. Tone mapping (i) : Use the
slider to adjust the amount of tone mapping that is applied to the image. If the value is set to zero, only the standard gamma correction is applied, while a higher value increases the visibility of the darkest and brightest parts in the image.

#### White balance

When the camera detects the color temperature of the incoming light, it can adjust the image to make the colors look more natural. If this is not sufficient, you can select a suitable light source from the list.

The automatic white balance setting reduces the risk of color flicker by adapting to changes gradually. If the lighting changes, or when the camera is first started, it can take up to 30 seconds to adapt to the new light source. If there is more than one type of light source in a scene, that is, they differ in color temperature, the dominating light source acts as a reference for the automatic white balance algorithm. This behavior can be overridden by choosing a fixed white balance setting that matches the light source you want to use as a reference.

#### Light environment:

- Automatic: Automatic identification and compensation for the light source color. This is the recommended setting which can be used in most situations.
  - Automatic outdoors  $\bigcup$ : Automatic identification and compensation for the light source color. This is the recommended setting which can be used in most outdoor situations.
  - Custom indoors  $\checkmark$ : Fixed color adjustment for a room with some artificial light other than fluorescent lighting and good for a normal color temperature around 2800 K.
  - Custom outdoors U: Fixed color adjustment for sunny weather conditions with a color temperature around 5500 K.
  - Fixed fluorescent 1: Fixed color adjustment for fluorescent lighting with a color temperature around 4000 K.
  - Fixed fluorescent 2: Fixed color adjustment for fluorescent lighting with a color temperature around 3000 K.
  - Fixed indoors: Fixed color adjustment for a room with some artificial light other than fluorescent lighting and good for a normal color temperature around 2800 K.
  - Fixed outdoors 1: Fixed color adjustment for sunny weather conditions with a color temperature around 5500 K.
  - Fixed outdoors 2: Fixed color adjustment for cloudy weather condition with a color temperature around 6500 K.
  - Street light mercury 💛 : Fixed color adjustment for ultraviolet emission in mercury vapor lights common in street lighting.
  - Street light sodium U: Fixed color adjustment that compensates for the yellow orange color of sodium vapor lights common in street lighting.
  - Hold current: Keep the current settings and do not compensate for light changes.
  - Manual  $\bigcup$ : Fix the white balance with the help of a white object. Drag the circle to an object that you want the camera to interpret as white in the live view image. Use the **Red balance** and **Blue balance** sliders to adjust the white balance manually.

Day-night mode

# The web interface

IR-cut filter:

#### is turned on and blocks incoming infrared light, and when in night mode, the IR-cut filter is turned off and the camera's light sensitivity increases. Note Some devices have IR-pass filters in night mode. The IR-pass filter increases IR-light sensitivity but blocks visible light. On: Select to turn on the IR-cut filter. The image is in color, but with reduced light sensitivity. Off: Select to turn off the IR-cut filter. The image is in black and white for increased light sensitivity. Threshold: Use the slider to adjust the light threshold where the camera changes from day mode to night mode. Move the slider towards Bright to decrease the threshold for the IR-cut filter. The camera changes to night mode earlier. Move the slider towards Dark to increase the threshold for the IR-cut filter. The camera changes to night mode later. If your device doesn't have built-in illumination, these controls are only available when you connect a supporting IR light Axis accessory. Allow illumination: Turn on to let the camera use the built-in light in night mode. Synchronize illumination: Turn on to automatically synchronize the illumination with the surrounding light. The synchronization between day and night only works if the IR-cut filter is set to Auto or Off.Automatic illumination angle : Turn on to use the automatic illumination angle. Turn off to set the illumination angle manually.Illumination angle : Use the slider to manually set the illumination angle, for example, if the angle needs to be different from the camera's angle of view. If the camera has a wide angle of view, you can set the illumination angle to a narrower angle, which equals a greater tele position. This will result in dark corners in the : Select the desired wavelength for the IR light. White light image.IR wavelength Allow illumination : Turn on to let the camera use white light in night mode.Synchronize illumination : Turn on to automatically synchronize the white light with the surrounding light.

Auto: Select to automatically turn on and off the IR-cut filter. When the camera is in day mode, the IR-cut filter

#### Exposure

Select an exposure mode to reduce rapidly changing irregular effects in the image, for example, flicker produced by different types of light sources. We recommend you to use the automatic exposure mode, or the same frequency as your power network.

#### Exposure mode:

- Automatic: The camera adjusts the aperture, gain, and shutter automatically.
- Automatic aperture  $\bigcirc$ : The camera adjusts the aperture and gain automatically. The shutter is fixed.
- Automatic shutter <sup>1</sup>: The camera adjusts the shutter and gain automatically. The aperture is fixed.
- Hold current: Locks the current exposure settings.
- Flicker-free  $\checkmark$ : The camera adjusts the aperture and gain automatically, and uses only the following shutter speeds: 1/50 s (50 Hz) and 1/60 s (60 Hz).
- Flicker-free 50 Hz  $\biguplus$  : The camera adjusts the aperture and gain automatically, and uses the shutter speed 1/50 s.
- Flicker-free 60 Hz iguarrow : The camera adjusts the aperture and gain automatically, and uses the shutter speed 1/60 s.
- Flicker-reduced  $\bigcirc$ : This is the same as flicker-free, but the camera might use shutter speeds faster than 1/100 s (50 Hz) and 1/120 s (60 Hz) for brighter scenes.
- Flicker-reduced 50 Hz  $\bigcirc$ : This is the same as flicker-free, but the camera might use shutter speeds faster than 1/100 s for brighter scenes.
- Flicker-reduced 60 Hz 💛 : This is the same as flicker-free, but the camera might use shutter speeds faster than 1/120 s for brighter scenes.

# The web interface

Manual     Ine aperture, gain, and shutter are fixed.
<b>Exposure zone</b> : Use exposure zones to optimize the exposure in a selected part of the scene, for example, the area in front of an entrance door.
Note The exposure zones are related to the original image (unrotated), and the names of the zones apply to the original image.
This means, for example, that if the video stream is rotated 90°, then the <b>Upper</b> zone becomes the <b>Right</b> zone in the stream, and <b>Left</b> becomes <b>Lower</b> .
<ul> <li>Automotive Critechie for most situations</li> </ul>
<ul> <li>Automatic: Suitable for most situations.</li> <li>Center: Uses a fixed area in the center of the image to calculate the exposure. The area has a fixed size and position in the live view.</li> </ul>
• Full : Uses the entire live view to calculate the exposure.
• Upper : Uses an area with a fixed size and position in the upper part of the image to calculate the exposure.
• Lower Uses an area with a fixed size and position in the lower part of the image to calculate the exposure.
• Left Uses an area with a fixed size and position in the left part of the image to calculate the exposure.
<ul> <li>Right U : Uses an area with a fixed size and position in the right part of the image to calculate the exposure.</li> <li>Spot: Uses an area with a fixed size and position in the live view to calculate the exposure.</li> </ul>
• Custom: Uses an area in the live view to calculate the exposure. You can adjust the size and position of the area.
Max shutter: Select the shutter speed to provide the best image. Low shutter speeds (longer exposure) might cause motion blur when there is movement, and a too high shutter speed might affect the image quality. Max shutter works with max gain to improve
the image.Max gain: Select the suitable max gain. If you increase the max gain, it improves the visible level of detail in dark
images, but also increases the noise level. More noise can also result in increased use of bandwidth and storage. If you set the max gain to a high value, images can differ a lot if the light conditions are very different from day to night. Max gain works with max
shutter to improve the image. Motion-adaptive exposure $\textcircled{0}$ : Select to reduce motion blur in low-light conditions. Blur-noise
trade-off: Use the slider to adjust the priority between motion blur and noise. If you want to prioritize low bandwidth and have
less noise at the expense of details in moving objects, move the slider towards Low noise. If you want to prioritize the preservation of details in moving objects at the expense of noise and bandwidth, move the slider towards Low motion blur. Note
You can change the exposure either by adjusting the exposure time or by adjusting the gain. If you increase the exposure
time, it results in more motion blur, and if you increase the gain, it results in more noise. If you adjust the Blur-noise
trade-off towards Low noise, the automatic exposure will prioritize longer exposure times over increasing gain, and the opposite if you adjust the trade-off towards Low motion blur. Both the gain and exposure time will eventually reach their maximum values in low-light conditions, regardless of the priority set.
Lock aperture U: Turn on to keep the aperture size set by the Aperture slider. Turn off to allow the camera to automatically
adjust the aperture size. You can, for example, lock the aperture for scenes with permanent light conditions. Aperture $\checkmark$ : Use the slider to adjust the aperture size, that is, how much light passes through the lens. To allow more light to enter the sensor and
thereby produce a brighter image in low-light conditions, move the slider towards <b>Open</b> . An open aperture also reduces the depth of field, which means that objects close to or far from the camera can appear unfocused. To allow more of the image to be in
focus, move the slider towards Closed.Exposure level: Use the slider to adjust the image exposure.Defog U: Turn on to detect the effects of foggy weather and automatically remove them for a clearer image. Note
We recommend you not to turn on <b>Defog</b> in scenes with low contrast, large light level variations, or when the autofocus is slightly off. This can affect the image quality, for example, by increasing the contrast. Furthermore, too much light can negatively impact the image quality when defog is active.

General

## The web interface

Name: Enter a name for the selected camera.

#### Optics

Temperature compensation : Turn on if you want the focus position to be corrected based on the temperature in the optics.IR compensation : Turn on if you want the focus position to be corrected when IR-cut filter is off and when there is IR light.Calibrate zoom and focus: Click to reset the optics and the zoom and focus settings to the factory default position. You need to do this if the optics have lost calibration during transport, or if the device has been exposed to extreme vibrations.

#### Stream

#### General

**Resolution**: Select the image resolution suitable for the surveillance scene. A higher resolution increases bandwidth and storage.**Frame rate**: To avoid bandwidth problems on the network or reduce storage size, you can limit the frame rate to a fixed amount. If you leave the frame rate at zero, the frame rate is kept at the highest possible rate under the current conditions. A higher frame rate requires more bandwidth and storage capacity.**P-frames**: A P-frame is a predicted image that shows only the changes in the image from the previous frame. Enter the desired number of P-frames. The higher the number, the less bandwidth is required. However, if there is network congestion, there could be a noticeable deterioration in the video quality.**Compression**: Use the slider to adjust the image compression. High compression results in a lower bitrate and lower image quality. Low compression

improves the image quality, but uses more bandwidth and storage when you record. Signed video  $\checkmark$ : Turn on to add the signed video feature to the video. Signed video protects the video from tampering by adding cryptographic signatures to the video.

#### Zipstream

Zipstream is a bitrate reduction technology, optimized for video surveillance, that reduces the average bitrate in an H.264 or H.265 stream in real time. Axis Zipstream applies a high bitrate in scenes where there are multiple regions of interest, for example, in scenes with moving objects. When the scene is more static, Zipstream applies a lower bitrate, and thereby reduces the required storage. To learn more, see *Reducing the bit rate with Axis Zipstream* 

Select the bitrate reduction **Strength**:

- Off: No bitrate reduction.
- Low: No visible quality degradation in most scenes. This is the default option and it can be used in all types of scenes to reduce the bitrate.
- Medium: Visible effects in some scenes through less noise and a slightly lower level of detail in regions of lower interest, for example, where there's no movement.
- High: Visible effects in some scenes through less noise and a lower level of detail in regions of lower interest, for example, where there's no movement. We recommend this level for cloud-connected devices and devices that use local storage.
- Higher: Visible effects in some scenes through less noise and a lower level of detail in regions of lower interest, for example, where there's no movement.
- Extreme: Visible effects in most scenes. The bitrate is optimized for smallest possible storage.

**Optimize for storage**: Turn on to minimize the bitrate while maintaining quality. The optimization does not apply to the stream shown in the web client. This can only be used if your VMS supports B-frames. Turning on **Optimize for storage** also turns on **Dynamic GOP.Dynamic FPS** (frames per second): Turn on to allow the bandwidth to vary based on the level of activity in the scene. More activity requires more bandwidth.Lower limit: Enter a value to adjust the frame rate between minimal fps and the stream default fps based on scene motion. We recommend you to use lower limit in scenes with very little motion, where the fps could drop to 1 or lower.Dynamic GOP (Group of Pictures): Turn on to dynamically adjust the interval between I-frames based on the level of activity in the scene.Upper limit: Enter a maximum GOP length, that is, the maximum number of P-frames between two I-frames. An I-frame is a self-contained image frame that is independent of other frames.

#### Bitrate control


# The web interface

Average: Select to automatically adjust the bitrate over a longer time period and provide the best possible image quality based on the available storage.
Click to calculate the target bitrate based on available storage, retention time, and bitrate limit.
Target bitrate: Enter desired target bitrate.
Retention time: Enter the number of days to keep the recordings.
Storage: Shows the estimated storage that can be used for the stream.
Maximum bitrate: Turn on to set a bitrate limit.
Bitrate limit: Enter a bitrate limit that is higher than the target bitrate.
Maximum: Select to set a maximum bitrate.
Variable: Select to allow the bitrate to vary based on the level of activity in the scene. More activity requires more bandwidth. We recommend this option for most situations.


#### Audio

Include: Turn on to use audio in the video stream.Source  $\bigcirc$ : Select what audio source to use.Stereo  $\bigcirc$ : Turn on to include built-in audio as well as audio from an external microphone.

#### **Overlays**



# The web interface



#### Privacy masks



### Radar

### Settings

General

Radar transmission: Use this to turn off the radar module completely.Channel 🙂 : If you have problems with multiple devices	
interfering with each other, select the same channel for up to four devices that are close to each other. For most installations, select	
Auto to let the devices automatically negotiate which channel to use. Mounting height: Enter the mounting height for the product.	
Note	
De se specific se very ser when you enter the recursting brinks. This below the device vieweling the redev detection in	

Be as specific as you can when you enter the mounting height. This helps the device visualize the radar detection in the correct position in the image.

#### Detection

Detection sensitivity: Select how sensitive the radar should be. A higher value means that you get a longer detection range, but there is also a higher risk of false alarms. A lower sensitivity decreases the number of false alarms, but it may shorten the detection range.Radar profile: Select a profile that suits your area of interest.

- Area monitoring: Track both large and small objects moving at lower speeds in open areas.
  - Ignore stationary rotating objects : Turn on to minimize false alarms from stationary objects with rotating movements, such as fans or turbines.
  - Ignore small objects: Turn on to minimize false alarms from small objects, such as cats or rabbits.
  - Ignore swaying objects: Turn on to minimize false alarms from swaying objects, such as trees, bushes, or flagpoles.
- Road monitoring: Track vehicles moving at higher speeds in urban zones and on suburban roads
  - Ignore stationary rotating objects : Turn on to minimize false alarms from stationary objects with rotating movements, such as fans or turbines.

: Select

Ignore swaying objects: Turn on to minimize false alarms from swaying objects, such as trees, bushes, or flagpoles.

#### View

Information legend: Turn on to show a legend containing the object types the radar can detect and track. Drag and drop to move the information legend. Zone opacity: Select how opaque or transparent the coverage zone should be. Grid opacity: Select

how opaque or transparent the grid should be.Color scheme: Select a theme for the radar visualization.Rotation the preferred orientation of the radar image.

**Object visualization** 

Trail lifetime: Select how long the trail of a tracked object is visible in the radar view.lcon style: Select the icon style of the tracked objects in the radar view. For plain triangles, select Triangle. For representative symbols, select Symbol. The icons will point in the direction the tracked objects are moving, regardless of style.

- Show information with icon: Select which information to display next to the icon of the tracked object:
  - **Object type**: Show the object type that the radar has detected.
  - Classification probability: Show how sure the radar is that the object classification is correct.
  - Velocity: Show how fast the object is moving.

#### Stream

#### General

**Resolution**: Select the image resolution suitable for the surveillance scene. A higher resolution increases bandwidth and storage.**Frame rate**: To avoid bandwidth problems on the network or reduce storage size, you can limit the frame rate to a fixed amount. If you leave the frame rate at zero, the frame rate is kept at the highest possible rate under the current conditions. A higher frame rate requires more bandwidth and storage capacity.**P-frames**: A P-frame is a predicted image that shows only the changes in the image from the previous frame. Enter the desired number of P-frames. The higher the number, the less bandwidth is required. However, if there is network congestion, there could be a noticeable deterioration in the video quality.**Compression**: Use the slider to adjust the image compression. High compression results in a lower bitrate and lower image quality. Low compression

improves the image quality, but uses more bandwidth and storage when you record.Signed video	U	: Turn on to add the
signed video feature to the video. Signed video protects the video from tampering by adding crypto	graph	nic signatures to the video.

#### Zipstream

Zipstream is a bitrate reduction technology, optimized for video surveillance, that reduces the average bitrate in an H.264 or H.265 stream in real time. Axis Zipstream applies a high bitrate in scenes where there are multiple regions of interest, for example, in scenes with moving objects. When the scene is more static, Zipstream applies a lower bitrate, and thereby reduces the required storage. To learn more, see *Reducing the bit rate with Axis Zipstream* 

Select the bitrate reduction **Strength**:

- Off: No bitrate reduction.
- Low: No visible quality degradation in most scenes. This is the default option and it can be used in all types of scenes to reduce the bitrate.
- Medium: Visible effects in some scenes through less noise and a slightly lower level of detail in regions of lower interest, for example, where there's no movement.
- High: Visible effects in some scenes through less noise and a lower level of detail in regions of lower interest, for example, where there's no movement. We recommend this level for cloud-connected devices and devices that use local storage.
- Higher: Visible effects in some scenes through less noise and a lower level of detail in regions of lower interest, for example, where there's no movement.
- Extreme: Visible effects in most scenes. The bitrate is optimized for smallest possible storage.

**Optimize for storage:** Turn on to minimize the bitrate while maintaining quality. The optimization does not apply to the stream shown in the web client. This can only be used if your VMS supports B-frames. Turning on **Optimize for storage** also turns on **Dynamic GOP.Dynamic FPS** (frames per second): Turn on to allow the bandwidth to vary based on the level of activity in the scene. More activity requires more bandwidth.Lower limit: Enter a value to adjust the frame rate between minimal fps and the stream default fps based on scene motion. We recommend you to use lower limit in scenes with very little motion, where the fps could drop to 1 or lower.Dynamic GOP (Group of Pictures): Turn on to dynamically adjust the interval between I-frames based on the level of activity in the scene.**Upper limit**: Enter a maximum GOP length, that is, the maximum number of P-frames between two I-frames. An I-frame is a self-contained image frame that is independent of other frames.

Bitrate control

# The web interface

• Average: Select to automatically adjust the bitrate over a longer time period and provide the best possible image quality based on the available storage.

- Click to calculate the target bitrate based on available storage, retention time, and bitrate limit.
- Target bitrate: Enter desired target bitrate.
- Retention time: Enter the number of days to keep the recordings.
- Storage: Shows the estimated storage that can be used for the stream.
- Maximum bitrate: Turn on to set a bitrate limit.
- **Bitrate limit**: Enter a bitrate limit that is higher than the target bitrate.
- Maximum: Select to set a maximum instant bitrate of the stream based on your network bandwidth.
   Maximum: Enter the maximum bitrate.
- Variable: Select to allow the bitrate to vary based on the level of activity in the scene. More activity requires more bandwidth. We recommend this option for most situations.

#### Audio

Include: Turn on to use audio in the video stream. Source  $\bigcirc$ : Select what audio source to use. Stereo  $\bigcirc$ : Turn on to include built-in audio as well as audio from an external microphone.

### Map calibration

Use map calibration to upload and calibrate a reference map. This will make it easier to see where objects move in the area covered by the radar.**Upload map**: Select the reference map you want to upload.**Set radar position on map**: Specify the position of the radar on the map, add a reference point straight in front of the radar and type the distance between the radar and the reference point. Click **Calibrate** to start the calibration. The result of the calibration is a reference map that displays the radar coverage in the appropriate scale.

#### Lanes

Lanes improve the radar's performance and ability to track vehicles when monitoring lanes on a	road. Add one lane in the radar
for each actual lane you are monitoring. + Add lane: Click to add a new lane. Use the mous	
lane you have added. : Click to expand and edit the name of the lane. : Click to de Turn on to activate the lanes you have added.	lete the lane.Lanes enabled:

#### **Exclude zones**

An exclude zone is an area in which moving objects are ignored. Use exclude zones if there are areas inside a scenario that trigger
a lot of unwanted alarms. : Click to create a new exclude zone.To modify an exclude zone, select it in the list. <b>Track</b>
passing objects: Turn on to track objects that pass through the exclude zone. The passing objects keep their track IDs and are visible throughout the zone. Objects that appear from within the exclude zone will not be tracked. Zone shape presets: Select the initial shape of the exclude zone.
• <b>Cover everything</b> : Select to set an exclude zone that covers the entire radar coverage area.
• Reset to box: Select to place a rectangular exclude zone in the middle of the coverage area.
To modify the shape of the zone, drag and drop any of the points on the lines. To remove a point, right-click on it.

## The web interface


#### **Scenarios**

A scenario is a combination of triggering conditions, as well as scene and detection settings. scenario. You can create up to 20 scenarios. Triggering conditions: Select the condition that will trigger alarms.
<ul> <li>Movement in area: Select if you want the scenario to trigger on objects moving in an area.</li> <li>Line crossing: Select if you want to the scenario to trigger on objects crossing one, or two, lines.</li> <li>Scene: Define the area or lines in the scenario where moving objects will trigger alarms.</li> </ul>
<ul> <li>For Movement in area, select one of the shape presets to modify the area.</li> <li>For Line crossing, drag and drop the line in the scene. To create more points on a line, click and drag anywhere on it. To remove a point, right-click on it.         <ul> <li>Require crossing of two lines: Turn on if the object must pass two lines before the scenario triggers an alarm.</li> <li>Change direction: Turn on if you want the scenario to trigger an alarm when objects cross the line in the other direction.</li> </ul> </li> <li>Detection settings: Define the trigger criteria for the scenario.</li> </ul>
<ul> <li>For Movement in area:         <ul> <li>Ignore short-lived objects: Set the delay in seconds from when the radar detects the object to when the scenario triggers an alarm. This can help to reduce false alarms.</li> <li>Trigger on object type: Select the type of objects (human, vehicle, unknown) you want the scenario to trigger on.</li> <li>Speed limit: Trigger on objects moving at speeds within a specific range.</li> <li>Invert: Select if you want to trigger on speeds above and below the set speed limit.</li> </ul> </li> <li>For Line crossing:         <ul> <li>Ignore short-lived objects: Set the delay in seconds from when the radar detects the object to when the scenario triggers an action. This can help to reduce false alarms. This option is not available for objects crossing two lines.</li> <li>Max time between crossings: Set the max time between crossing the first line and the second line. This option is only available for objects crossing two lines.</li> <li>Trigger on object type: Select the type of objects (human, vehicle, unknown) you want the scenario to trigger on.</li> <li>Speed limit: Trigger on objects moving at speeds within a specific range.</li> <li>Invert: Select if you want to trigger on speeds above and below the set speed limit.</li> </ul> </li> </ul>
• Minimum trigger duration: Set the minimum duration for the triggered alarm.

#### **Overlays**

- Click to add an overlay. Select the type of overlay from the dropdown list:
   Text: Select to show a text that is integrated in the live view image and visible in all views, recordings and snapshots. You can enter your own text, and you can also include pre-configured modifiers to automatically show, for example,
  - time, date, and frame rate.
    - $\blacksquare$  : Click to add the date modifier F to show yyyy-mm-dd.
    - ${f O}$  : Click to add the time modifier  ${}^{\$}{X}$  to show hh:mm:ss (24-hour clock).
    - Modifiers: Click to select any of the modifiers shown in the list to add them to the text box. For example, %a shows the day of the week.
    - Size: Select the desired font size.
    - Appearance: Select the text color and background color, for example, white text on a black background (default).
    - - : Select the position of the overlay in the image.
  - Image: Select to show a static image superimposed over the video stream. You can use .bmp, .png, .jpeg, or .svg files. To upload an image, click Images. Before you upload an image, you can choose to:

## The web interface



- Size: Select the size of the overlay.
<ul> <li>Visible on all channels: Turn off to show only on your currently selected channel. Turn on to show on all active channels.</li> </ul>
- <b>Update interval</b> : Choose the time between data updates.
- <b>Transparency</b> : Set the transparency of the entire overlay.
- <b>Background transparency</b> : Set the transparency only of the background of the overlay.
- Points: Turn on to add a point to the graph line when data is updated.
- Yaxis
- Label: Enter the text label for the y axis.
<ul> <li>Dynamic scale: Turn on for the scale to automatically adapt to the data values. Turn off to manually enter values for a fixed scale.</li> </ul>

- Min alarm threshold and Max alarm threshold: These values will add horizontal reference lines to the bar chart, making it easier to see when the data value becomes too high or too low.

### Radar PTZ autotracking

Pair the radar with a PTZ camera to use radar autotracking. To establish the connection, go to System > Edge-to-edge.

Configure initial settings:**Camera mounting height**: The distance from the ground to the height of the mounted PTZ camera.**Pan alignment**: Pan the PTZ camera so that it points in the same direction as the radar. Click on the IP address of the PTZ camera to access it. **Save pan offset**: Click to save the pan alignment.**Ground incline offset**: Use the ground incline offset to fine tune the camera's tilt. If the ground is sloped, or if the camera is not mounted horizontally, the camera may aim too high or too low when tracking an object. **Done**: Click to save your settings and continue with the configuration.

Configure PTZ autotracking:**Track**: Select if you want to track humans, vehicles and/or unknown objects.**Tracking**: Turn on to start tracking objects with the PTZ camera. The tracking automatically zooms in on an object, or a group of objects, to keep them in the view of the camera.**Object switching**: If the radar detects multiple objects that won't fit in the PTZ camera's view, the PTZ camera tracks the object that the radar gives the highest priority, and ignores the others.**Object hold time**: Determines for how many seconds the PTZ camera should track each object.**Return to home**: Turn on to make the PTZ camera return to its home position when the radar no longer tracks any objects.**Return to home timeout**: Determines how long the PTZ camera should stay at the tracked objects last known position before returning to home.**Zoom**: Use the slider to fine tune the zoom of the PTZ camera.**Reconfigure installation**: Click to clear all settings and go back to the initial configuration.

# Analytics

### **AXIS Object Analytics**

**Start**: Click to start AXIS Object Analytics. The application will run in the background, and you can create rules for events based on the application's current settings.**Open**: Click to open AXIS Object Analytics. The application opens up in a new window where you

can configure its settings. **Not installed**: AXIS Object Analytics is not installed on this device. Upgrade AXIS OS to the latest version to get the latest version of the application.

## Audio

### **Device settings**

Input: Turn on or off audio input. Shows the type of input.

## The web interface

Input type i: Select the type of input, for instance, if it's internal microphone or line. Power type i: Select power type
for your input. Apply changes 🛈 : Apply your selection. Echo cancellation 🛈 : Turn on to remove echoes during two-way
communication.Separate gain controls : Turn on to adjust the gain separately for the different input types.Automatic
gain control : Turn on to dynamically adapt the gain to changes in the sound.Gain: Use the slider to change the gain. Click the microphone icon to mute or unmute.

#### Output: Shows the type of output.


Gain: Use the slider to change the gain. Click the speaker icon to mute or unmute.

#### Stream

**Encoding**: Select the encoding to use for the input source streaming. You can only choose encoding if audio input is turned on. If audio input is turned off, click **Enable audio input** to turn it on.

Echo cancellation: Turn on to remove echoes during two-way communication.

### Audio clips



#### Audio enhancement

#### Input

Ten Band Graphic Audio Equalizer: Turn on to adjust the level of different frequency bands within an audio signal. This feature is
for advanced users with audio configuration experience.Talkback range (i) : Choose the operational range to gather audio
for advanced users with audio configuration experience.Talkback range 💙 : Choose the operational range to gather audio
content. An increase to the operational range cause a reduction of simultaneous two-way communication capabilities. Voice
enhancement is Turn on to enhance the voice content in relation to other sounds.
enhancement 💛 : Turn on to enhance the voice content in relation to other sounds.

### Recordings

Г

Ongoing recordings: Show all ongoing recordings on the device.	• Start a recording on the device. Choose which
storage device to save to. Stop a recording on the device.Trig device is shut down.Continuous recordings will continue until man will continue when the device starts up again.	gered recordings will end when manually stopped or when the ually stopped. Even if the device is shut down, the recording

## The web interface

Stop playing the recording. Play the recording. Show or hide information and options about the recording.Set export range: If you only want to export part of the recording, enter a time span. Note that if you work in a different time zone than the location of the device, the time span is based on the device's time zone. Encrypt: Select to set a password for exported recordings. It will not be possible to open the exported file without the password. Click to delete a recording.Export: Export the whole or a part of the recording. Click to filter the recordings.From: Show recordings done after a certain point in time.To: Show recordings up until a certain point in time.Source 🕕 : Show recordings based on source. The source refers to the sensor.Event: Show recordings based on events.Storage: Show recordings based on storage type. Apps Add app: Install a new app.Find more apps: Find more apps to install. You will be taken to an overview page of Axis : Turn on to allow installation of unsigned apps.Allow root-privileged apps apps.Allow unsigned apps : Turn on to View the security updates in AXIS OS and ACAP apps. allow apps with root privileges full access to the device. Note The device's performance might be affected if you run several apps at the same time. Use the switch next to the app name to start or stop the app.Open: Access the app's settings. The available settings depend on the application. Some applications don't have any settings. The context menu can contain one or more of the following options: Open-source license: View information about open-source licenses used in the app. App log: View a log of the app events. The log is helpful when you contact support. Activate license with a key: If the app requires a license, you need to activate it. Use this option if your device doesn't have internet access. If you don't have a license key, go to axis.com/products/analytics. You need a license code and the Axis product serial number to generate a license key. Activate license automatically: If the app requires a license, you need to activate it. Use this option if your device has internet access. You need a license code to activate the license. Deactivate the license: Deactivate the license to replace it with another license, for example, when you change from a trial license to a full license. If you deactivate the license, you also remove it from the device. Settings: Configure the parameters.

• Delete: Delete the app permanently from the device. If you don't deactivate the license first, it remains active.

## System

#### Time and location

Date and time

The time format depends on the web browser's language settings.

Note

We recommend you synchronize the device's date and time with an NTP server.

## The web interface

Synchronization: Select an option for the device's date and time synchronization. Automatic date and time (manual NTS KE servers): Synchronize with the secure NTP key establishment servers connected to the DHCP server. Manual NTS KE servers: Enter the IP address of one or two NTP servers. When you use two NTP servers, the device synchronizes and adapts its time based on input from both. Max NTP poll time: Select the maximum amount of time the device should wait before it polls the NTP server to get an updated time. Min NTP poll time: Select the minimum amount of time the device should wait before it polls the NTP server to get an updated time. Automatic date and time (NTP servers using DHCP): Synchronize with the NTP servers connected to the DHCP server. Fallback NTP servers: Enter the IP address of one or two fallback servers. Max NTP poll time: Select the maximum amount of time the device should wait before it polls the NTP server to get an updated time. Min NTP poll time: Select the minimum amount of time the device should wait before it polls the NTP server to get an updated time. Automatic date and time (manual NTP servers): Synchronize with NTP servers of your choice. Manual NTP servers: Enter the IP address of one or two NTP servers. When you use two NTP servers, the device synchronizes and adapts its time based on input from both. Max NTP poll time: Select the maximum amount of time the device should wait before it polls the NTP server to get an updated time. Min NTP poll time: Select the minimum amount of time the device should wait before it polls the NTP server to get an updated time. Custom date and time: Manually set the date and time. Click Get from system to fetch the date and time settings once from your computer or mobile device. Time zone: Select which time zone to use. Time will automatically adjust to daylight saving time and standard time. DHCP: Adopts the time zone of the DHCP server. The device must connected to a DHCP server before you can select this option Manual: Select a time zone from the drop-down list. Note The system uses the date and time settings in all recordings, logs, and system settings.

#### **Device** location

Enter where the device is located. Your video management system can use this information to place the device on a map.

- Latitude: Positive values are north of the equator.
- Longitude: Positive values are east of the prime meridian.
- Heading: Enter the compass direction that the device is facing. 0 is due north.
- Label: Enter a descriptive name for the device.
- Save: Click to save your device location.

#### Regional settings

Sets the system of measurement to use in all system settings.

Metric (m, km/h): Select for distance measurement to be in meters and speed measurement to be in kilometers per hour.U.S. customary (ft, mph): Select for distance measurement to be in feet and speed measurement to be in miles per hour.

#### Network

IPv4

Assign IPv4 automatically: Select to let the network router assign an IP address to the device automatically. We recommend automatic IP (DHCP) for most networks.IP address: Enter a unique IP address for the device. Static IP addresses can be assigned at random within isolated networks, provided that each address is unique. To avoid conflicts, we recommend you contact your network administrator before you assign a static IP address.Subnet mask: Enter the subnet mask to define what addresses are inside the local area network. Any address outside the local area network goes through the router.Router: Enter the IP address of the default router (gateway) used to connect devices that are attached to different networks and network segments.Fallback to static IP address if DHCP isn't available: Select if you want to add a static IP address to use as fallback if DHCP is unavailable and can't assign an IP address automatically. Note

If DHCP isn't available and the device uses a static address fallback, the static address is configured with a limited scope.

#### IPv6

Assign IPv6 automatically: Select to turn on IPv6 and to let the network router assign an IP address to the device automatically.

#### Hostname

Assign hostname automatically: Select to let the network router assign a hostname to the device automatically.Hostname: Enter the hostname manually to use as an alternative way of accessing the device. The server report and system log use the hostname. Allowed characters are A–Z, a-z, 0-9 and –.

#### DNS servers

Assign DNS automatically: Select to let the DHCP server assign search domains and DNS server addresses to the device automatically. We recommend automatic DNS (DHCP) for most networks.Search domains: When you use a hostname that is not fully qualified, click Add search domain and enter a domain in which to search for the hostname the device uses.DNS servers: Click Add DNS server and enter the IP address of the DNS server. This provides the translation of hostnames to IP addresses on your network.

#### HTTP and HTTPS

HTTPS is a protocol that provides encryption for page requests from users and for the pages returned by the web server. The encrypted exchange of information is governed by the use of an HTTPS certificate, which guarantees the authenticity of the server.

To use HTTPS on the device, you must install an HTTPS certificate. Go to System > Security to create and install certificates.

Allow access through: Select if a user is allowed to connect to the device through the HTTP, HTTPS, or both HTTP and HTTPS protocols.

Note

If you view encrypted web pages through HTTPS, you might experience a drop in performance, especially when you request a page for the first time.

HTTP port: Enter the HTTP port to use. The device allows port 80 or any port in the range 1024-65535. If you are logged in as an administrator, you can also enter any port in the range 1-1023. If you use a port in this range, you get a warning.HTTPS port: Enter the HTTPS port to use. The device allows port 443 or any port in the range 1024-65535. If you are logged in as an administrator, you can also enter any port in the range 1-1023. If you use a port in this range, you get a warning.Certificate: Select a certificate to enable HTTPS for the device.

#### Network discovery protocols

**Bonjour**<sup>®</sup>: Turn on to allow automatic discovery on the network.**Bonjour name**: Enter a friendly name to be visible on the network. The default name is the device name and MAC address.**UPnP**<sup>®</sup>: Turn on to allow automatic discovery on the network.**UPnP name**: Enter a friendly name to be visible on the network. The default name is the device name and MAC address.**WS-Discovery**: Turn on to allow automatic discovery on the network.**LLDP and CDP**: Turn on to allow automatic discovery on the network. Turning LLDP and CDP off can impact the PoE power negotiation. To resolve any issues with the PoE power negotiation, configure the PoE switch for hardware PoE power negotiation only.

#### One-click cloud connection

One-click cloud connection (03C) together with an 03C service provides easy and secure internet access to live and recorded video from any location. For more information, see *axis.com/end-to-end-solutions/hosted-services*.

#### Allow 03C:

- **One-click**: This is the default setting. Press and hold the control button on the device to connect to an O3C service over the internet. You need to register the device with the O3C service within 24 hours after you press the control button. Otherwise, the device disconnects from the O3C service. Once you register the device, **Always** is enabled and the device stays connected to the O3C service.
  - Always: The device constantly attempts to connect to an O3C service over the internet. Once you register the device, it stays connected to the O3C service. Use this option if the control button on the device is out of reach.
  - No: Disables the O3C service.

**Proxy settings:** If needed, enter the proxy settings to connect to the proxy server.**Host**: Enter the proxy server's address.**Port**: Enter the port number used for access.**Login** and **Password**: If needed, enter username and password for the proxy server.**Authentication method**:

- **Basic**: This method is the most compatible authentication scheme for HTTP. It's less secure than the **Digest** method because it sends the username and password unencrypted to the server.
- Digest: This method is more secure because it always transfers the password encrypted across the network.
- Auto: This option lets the device select the authentication method depending on the supported methods. It prioritizes the Digest method over the Basic method.

**Owner authentication key (OAK):** Click **Get key** to fetch the owner authentication key. This is only possible if the device is connected to the internet without a firewall or proxy.

#### SNMP

The Simple Network Management Protocol (SNMP) allows remote management of network devices.

SNMP: Select the version of SNMP to use.						
	• v1 and v2c:					
	<ul> <li>Read community: Enter the community name that has read-only access to all supported SNMP objects. The default value is public.</li> </ul>					
	<ul> <li>Write community: Enter the community name that has read or write access to all supported SNMP objects (except read-only objects). The default value is write.</li> </ul>					
	<ul> <li>Activate traps: Turn on to activate trap reporting. The device uses traps to send messages for important events or status changes to a management system. In the web interface, you can set up traps for SNMP v1 and v2c. Traps are automatically turned off if you change to SNMP v3 or turn off SNMP. If you use SNMP v3, you can set up traps through the SNMP v3 management application.</li> </ul>					
	- <b>Trap address:</b> Enter the IP address or host name of the management server.					
	<ul> <li>Trap community: Enter the community to use when the device sends a trap message to the management system.</li> </ul>					
	- Traps:					
	- Cold start: Sends a trap message when the device starts.					
	- Warm start: Sends a trap message when you change an SNMP setting.					
	- Link up: Sends a trap message when a link changes from down to up.					
	- Authentication failed: Sends a trap message when an authentication attempt fails.					
Note						
	All Axis Video MIB traps are enabled when you turn on SNMP v1 and v2c traps. For more information, see AXIS OS Portal $>$ SNMP.					
	<ul> <li>v3: SNMP v3 is a more secure version, which provides encryption and secure passwords. To use SNMP v3, we recommend you to activate HTTPS, as the password is then sent through HTTPS. This also prevents unauthorized parties' access to unencrypted SNMP v1 and v2c traps. If you use SNMP v3, you can set up traps through the SNMP v3 management application.</li> </ul>					
	<ul> <li>Password for the account "initial": Enter the SNMP password for the account named "initial". Although the password can be sent without activating HTTPS, we don't recommend it. The SNMP v3 password can only be set once, and preferably only when HTTPS is enabled. Once the password is set, the password field is no longer displayed. To set the password again, you must reset the device to factory default settings.</li> </ul>					

#### Power over Ethernet

#### Security

Certificates

Certificates are used to authenticate devices on a network. The device supports two types of certificates:
Client/server certificates
A client/server certificate validates the device's identity, and can be self-signed or issued by a Certificate Authority (CA). A self-signed certificate offers limited protection and can be used before a CA-issued certificate has been obtained. • CA certificates
You can use a CA certificate to authenticate a peer certificate, for example to validate the identity of an authentication server when the device connects to a network protected by IEEE 802.1X. The device has several pre-installed CA certificates.
These formats are supported:
<ul> <li>Certificate formats: .PEM, .CER, and .PFX</li> </ul>
<ul> <li>Private key formats: PKCS#1 and PKCS#12</li> </ul>
Important
If you reset the device to factory default, all certificates are deleted. Any pre-installed CA certificates are reinstalled.
in you reset the device to factory default, an eleftificates are deleted. Any pre-instance ex certificates are reinstance.
Add certificate : Click to add a certificate.
~
More : Show more fields to fill in or select.
<ul> <li>Secure keystore: Select to use Secure element or Trusted Platform Module 2.0 to securely store the private key. For more information on which secure keystore to select, go to <i>help.axis.com/en-us/axis-os#cryptographic-support</i>.</li> <li>Key type: Select the default or a different encryption algorithm from the drop-down list to protect the certificate.</li> </ul>
The context menu contains:
• Certificate information: View an installed certificate's properties.
• Delete certificate: Delete the certificate.
• Create certificate signing request: Create a certificate signing request to send to a registration authority to apply
for a digital identity certificate.
Secure keystore 0 :
Secure element (CC EAL6+): Select to use secure element for secure keystore.
• Trusted Platform Module 2.0 (CC EAL4+, FIPS 140-2 Level 2): Select to use TPM 2.0 for secure keystore.

Network access control and encryption

IEEE 802.1xIEEE 802.1x is an IEEE standard for port-based network admission control providing secure authentication of wired and wireless network devices. IEEE 802.1x is based on EAP (Extensible Authentication Protocol). To access a network protected by IEEE 802.1x, network devices must authenticate themselves. The authentication is performed by an authentication server, typically a RADIUS server (for example, FreeRADIUS and Microsoft Internet Authentication Server). IEEE 802.1AE MACsecIEEE 802.1AE MACsec is an IEEE standard for media access control (MAC) security that defines connectionless data confidentiality and integrity for media access independent protocols. Certificates When configured without a CA certificate, server certificate validation is disabled and the device tries to authenticate itself regardless of what network it is connected to.When using a certificate, in Axis' implementation, the device and the authentication server authenticate themselves with digital certificates using EAP-TLS (Extensible Authentication Protocol - Transport Layer Security). To allow the device to access a network protected through certificates, you must install a signed client certificate on the device. Authentication method: Select an EAP type used for authentication.Client certificate: Select a client certificate to use IEEE 802.1x. The authentication server uses the certificate to validate the client's identity.CA certificates: Select CA certificates to validate the authentication server's identity. When no certificate is selected, the device tries to authenticate itself regardless of what network it is connected to EAP identity: Enter the user identity associated with the client certificate. EAPOL version: Select the EAPOL version that is used in the network switch. Use IEEE 802.1x: Select to use the IEEE 802.1x protocol. These settings are only available if you use IEEE 802.1x PEAP-MSCHAPv2 as the authentication method:

- **Password**: Enter the password for your user identity.
- Peap version: Select the Peap version that is used in the network switch.
- Label: Select 1 to use client EAP encryption; select 2 to use client PEAP encryption. Select the Label that the network switch uses when using Peap version 1.

These settings are only available if you use IEEE 802.1ae MACsec (Static CAK/Pre-Shared Key) as the authentication method:

- Key agreement connectivity association key name: Enter the connectivity association name (CKN). It must be 2 to 64 (divisible by 2) hexadecimal characters. The CKN must be manually configured in the connectivity association and must match on both ends of the link to initially enable MACsec.
- Key agreement connectivity association key: Enter the connectivity association key (CAK). It should be either 32 or 64 hexadecimal characters long. The CAK must be manually configured in the connectivity association and must match on both ends of the link to initially enable MACsec.

#### Prevent brute-force attacks

**Blocking:** Turn on to block brute-force attacks. A brute-force attack uses trial-and-error to guess login info or encryption keys.**Blocking period:** Enter the number of seconds to block a brute-force attack.**Blocking conditions:** Enter the number of authentication failures allowed per second before the block starts. You can set the number of failures allowed both on page level and device level.

#### Firewall

Activate: Turn on the firewall.

Default Policy: Select the default state for the firewall.

- Allow: Allows all connections to the device. This option is set by default.
- Deny: Denies all connections to the device.

To make exceptions to the default policy, you can create rules that allows or denies connections to the device from specific addresses, protocols, and ports.

- Address: Enter an address in IPv4/IPv6 or CIDR format that you want to allow or deny access to.
- **Protocol**: Select a protocol that you want to allow or deny access to.
- Port: Enter a port number that you want to allow or deny access to. You can add a port number between 1 and 65535.
- Policy: Select the policy of the rule.

+

: Click to create another rule.

Add rules: Click to add the rules that you have defined.

- Time in seconds: Set a time limit for testing the rules. The default time limit is set to 300 seconds. To activate the rules straight away, set the time to 0 seconds.
- **Confirm rules:** Confirm the rules and their time limit. If you have set a time limit of more than 1 second, the rules will be active during this time. If you have set the time to 0, the rules will be active straight away.

Pending rules: An overview of the latest tested rules that you are yet to confirm.

~

#### Note

S0

The rules that have a time limit appear under Active rules until the displayed timer runs out, or until you confirm them. If you don't confirm them, they will appear under Pending rules once the timer runs out, and the firewall will revert to the previously defined settings. If you confirm them, they will replace the current active rules.

Confirm rules: Click to activate the pending rules. Active rules: An overview of the rules you are currently running on the device.

|--|

#### Custom signed AXIS OS certificate

٠

To install test software or other custom software from Axis on the device, you need a custom signed AXIS OS certificate. The certificate verifies that the software is approved by both the device owner and Axis. The software can only run on a specific device which is identified by its unique serial number and chip ID. Only Axis can create custom signed AXIS OS certificates, since Axis holds the key to sign them.**Install**: Click to install the certificate. You need to install the certificate before you install the

	•				
ftware.	•	The	context	menu	contains

• Delete certificate: Delete the certificate.

#### Accounts

Accounts

Add account: Click to add a new account. You can add up to 100 accounts.Account: Enter a unique account name.New password: Enter a password for the account. Passwords must be 1 to 64 characters long. Only ASCII printable characters (code 32 to 126) are allowed in the password, for example, letters, numbers, punctuation, and some symbols.Repeat password: Enter the same password again.Privileges:

- Administrator: Has full access to all settings. Administrators can also add, update, and remove other accounts.
  - Operator: Has access to all settings except:
    - All System settings.

• The context menu contains: **Update account**: Edit the account properties. **Delete account**: Delete the account. You can't delete the root account.

#### Anonymous access

Allow anonymous viewing: Turn on to allow anyone access the device as a viewer without logging in with an account.Allow anonymous PTZ operating : Turn on to allow anonymous users to pan, tilt, and zoom the image.

#### SSH accounts

Add SSH account: Click to add a new SSH account.

- Restrict root access: Turn on to restrict functionality that requires root access.
- Enable SSH: Turn on to use SSH service.

Account: Enter a unique account name.New password: Enter a password for the account. Passwords must be 1 to 64 characters long. Only ASCII printable characters (code 32 to 126) are allowed in the password, for example, letters, numbers, punctuation,

and some symbols.**Repeat password**: Enter the same password again.**Comment**: Enter a comment (optional). • The context menu contains:**Update SSH account**: Edit the account properties.**Delete SSH account**: Delete the account. You can't delete the root account.

#### **OpenID** Configuration

#### Important

If you can't use OpenID to sign in, use the Digest or Basic credentials you used when you configured OpenID to sign in.

Client ID: Enter the OpenID username.Outgoing Proxy: Enter the proxy address for the OpenID connection to use a proxy server.Admin claim: Enter a value for the admin role.Provider URL: Enter the web link for the API endpoint authentication. Format should be https://[insert URL]/.well-known/openid-configurationOperator claim: Enter a value for the operator role.Require claim: Enter the data that should be in the token.Viewer claim: Enter the value for the viewer role.Remote user: Enter a value to identify remote users. This assists to display the current user in the device's web interface.Scopes: Optional scopes that could be part of the token.Client secret: Enter the OpenID password Save: Click to save the OpenID values.Enable OpenID: Turn on to close current connection and allow device authentication from the provider URL.

### Events

#### Rules

A rule defines the conditions that triggers the product to perform an action. The list shows all the currently configured rules in the product.

#### Note

You can create up to 256 action rules.

## The web interface

Add a rule: Create a rule.Name: Enter a name for the rule.Wait between actions: Enter the minimum time (hh:mm:ss) that must pass between rule activations. It is useful if the rule is activated by, for example, day-night mode conditions, to avoid that small light changes during sunrise and sunset activate the rule repeatedly.Condition: Select a condition from the list. A condition must be met for the device to perform an action. If multiple conditions are defined, all of them must be met to trigger the action. For information about specific conditions, see *Get started with rules for events*.Use this condition as a trigger: Select to make this first condition function only as a starting trigger. It means that once the rule is activated, it remains active for as long as all the other conditions are met, no matter the state of the first condition. If you don't select this option, the rule will simply be active whenever all the conditions are met.Invert this condition: Select if you want the condition to be the opposite of your


selection. Add a condition: Click to add an additional condition. Action: Select an action from the list and enter its required information. For information about specific actions, see *Get started with rules for events*.

#### Recipients

You can set up your device to notify recipients about events or send files. The list shows all the recipients currently configured in the product, along with information about their configuration.

#### Note

You can create up to 20 recipients.



# The web interface

-	Host: Enter the IP address or hostname for the network storage.
-	Share: Enter the name of the share on the host.
-	Folder: Enter the path to the directory where you want to store files.
-	Username: Enter the username for the login.
-	Password: Enter the password for the login.
<ul> <li>SFTP</li> </ul>	
-	Host: Enter the server's IP address or hostname. If you enter a hostname, make sure that a DNS server is
	specified under System > Network > IPv4 and IPv6.
-	<b>Port:</b> Enter the port number used by the SFTP server. The default is 22.
-	Folder: Enter the path to the directory where you want to store files. If this directory doesn't already exist on the SFTP server, you will get an error message when uploading files.
-	Username: Enter the username for the login.
-	Password: Enter the password for the login.
-	SSH host public key type (MD5): Enter the fingerprint of the remote host's public key (a 32-digit
	hexadecimal string). The SFTP client supports SFTP servers using SSH-2 with RSA, DSA, ECDSA, and ED25519
	host key types. RSA is the preferred method during negotiation, followed by ECDSA, ED25519, and DSA. Make
	sure to enter the right MD5 host key that is used by your SFTP server. While the Axis device supports both
	MD5 and SHA-256 hash keys, we recommend using SHA-256 due to stronger security over MD5. For more
	information on how to configure an SFTP server with an Axis device, go to the AXIS OS Portal. SSH host public key type (SHA256): Enter the fingerprint of the remote host's public key (a 43-digit Base64
-	encoded string). The SFTP client supports SFTP servers using SSH-2 with RSA, DSA, ECDSA, and ED25519 host
	key types. RSA is the preferred method during negotiation, followed by ECDSA, ED25519, and DSA. Make
	sure to enter the right MD5 host key that is used by your SFTP server. While the Axis device supports both
	MD5 and SHA-256 hash keys, we recommend using SHA-256 due to stronger security over MD5. For more
	information on how to configure an SFTP server with an Axis device, go to the AXIS OS Portal.
-	Use temporary file name: Select to upload files with temporary, automatically generated filenames. The
	files get renamed to the desired names when the upload completes. If the upload is aborted or interrupted,
	you don't get any corrupt files. However, you probably still get the temporary files. This way, you know
	that all tiles that have the desired name are correct
	that all files that have the desired name are correct.
• SIP o	r VMS :
SIP: S	r VMS 🚺 :
SIP: S VMS: -	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list.
SIP: 5 VMS: - -	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address.
SIP: 5 VMS: - -	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works.
SIP: S VMS: - - - Email	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works.
SIP: 5 VMS: - -	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to
SIP: S VMS: - - - Email	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them.
SIP: SIP: S VMS: - - - Email	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to
SIP: S VMS: - - Email	r VMS : Select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication.
SIP: S VMS: - - Email	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require
SIP: S VMS: - - Email - - -	<ul> <li>r VMS :</li> <li>is select to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> </ul> Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication.
SIP: S VMS: - - Email - - - -	<ul> <li>r VMS :</li> <li>is select to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> </ul> Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com.
SIP: S VMS: - - Email - - - - -	<ul> <li>r VMS :</li> <li>is select to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> </ul> Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587.
SIP: S VMS: - - Email - - - -	<ul> <li>r VMS :</li> <li>is select to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> </ul> Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS.
SIP: S VMS: - - Email - - - - - - - - - - - - - - - - -	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS. Validate server certificate: If you use encryption, select to validate the identity of the device. The certificate
SIP: S VMS: - - Email - - - - - - - - - - - - - - - - -	<ul> <li>r VMS :</li> <li>is select to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> </ul> Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS.
SIP: S VMS: - - Email - - - - - - - - - - - - - - - - -	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS. Validate server certificate: If you use encryption, select to validate the identity of the device. The certificate can be self-signed or issued by a Certificate Authority (CA).
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	r VMS : select to make a SIP call. Select to make a VMS call. From SIP account: Select from the list. To SIP address: Enter the SIP address. Test: Click to test that your call settings works. Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them. Send email from: Enter the email address of the sending server. Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication. Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication. Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com. Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS. Validate server certificate: If you use encryption, select to validate the identity of the device. The certificate can be self-signed or issued by a Certificate Authority (CA).
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	<ul> <li>r VMS</li> <li>:</li> <l< td=""></l<></ul>
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	<ul> <li>r VMS</li> <li>is identified to make a SIP call.</li> <li>Select to make a VMS call.</li> <li>From SIP account: Select from the list.</li> <li>To SIP address: Enter the SIP address.</li> <li>Test: Click to test that your call settings works.</li> <li>Send email to: Enter the email address to send emails to. To enter multiple addresses, use commas to separate them.</li> <li>Send email from: Enter the email address of the sending server.</li> <li>Username: Enter the username for the mail server. Leave this field empty if the mail server does not require authentication.</li> <li>Password: Enter the password for the mail server. Leave this field empty if the mail server does not require authentication.</li> <li>Email server (SMTP): Enter the name of the SMTP server, for example, smtp.gmail.com, smtp.mail.yahoo.com.</li> <li>Port: Enter the port number for the SMTP server, using values in the range 0-65535. The default value is 587. Encryption: To use encryption, select either SSL or TLS.</li> <li>Validate server certificate: If you use encryption, select to validate the identity of the device. The certificate can be self-signed or issued by a Certificate Authority (CA).</li> <li>POP authentication: Turn on to enter the name of the POP server, for example, pop.gmail.com.</li> </ul>
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	<ul> <li>r VMS</li> <li>:</li> <l< td=""></l<></ul>
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	<ul> <li>r VMS</li> <li>:</li> <l< td=""></l<></ul>
SIP: S VMS: - - - - - - - - - - - - - - - - - - -	<ul> <li>r VMS</li> <li>:</li> <l< td=""></l<></ul>

- **Port:** Enter the port number used to access the server.

# The web interface

**Test**: Click to test the setup. The context menu contains:**View recipient**: Click to view all the recipient details.**Copy recipient**: Click to copy a recipient. When you copy, you can make changes to the new recipient.**Delete recipient**: Click to delete the recipient permanently.

#### Schedules

Schedules and pulses can be used as conditions in rules. The list shows all the schedules and pulses currently configured in the product, along with information about their configuration.

Add schedule: Click to create a schedule or pulse.

#### Manual triggers

You can use the manual trigger to manually trigger a rule. The manual trigger can, for example, be used to validate actions during product installation and configuration.

#### MQTT

MQTT (Message Queuing Telemetry Transport) is a standard messaging protocol for the Internet of Things (IoT). It was designed for simplified IoT integration and is used in a wide variety of industries to connect remote devices with a small code footprint and minimal network bandwidth. The MQTT client in Axis device software can simplify integration of data and events produced in the device to systems which are not video management software (VMS).Set up the device as an MQTT client. MQTT communication is based on two entities, the clients and the broker. The clients can send and receive messages. The broker is responsible for routing messages between clients.You can learn more about MQTT in *AXIS OS Portal*.

#### ALPN

ALPN is a TLS/SSL extension that allows for the selection of an application protocol during the handshake phase of the connection between the client and server. This is used to enable MQTT traffic over the same port that is used for other protocols, such as HTTP. In some cases, there might not be a dedicated port open for MQTT communication. A solution in such cases is to use ALPN to negotiate the use of MQTT as the application protocol on a standard port, allowed by the firewalls.

#### MQTT client

**Connect:** Turn on or off the MQTT client.**Status:** Shows the current status of the MQTT client.**BrokerHost:** Enter the hostname or IP address of the MQTT server.**Protocol:** Select which protocol to use.**Port:** Enter the port number.

- 1883 is the default value for MQTT over TCP
- 8883 is the default value for MQTT over SSL
- 80 is the default value for MQTT over WebSocket
- 443 is the default value for MQTT over WebSocket Secure

ALPN protocol: Enter the ALPN protocol name provided by your MQTT broker provider. This is only applicable with MQTT over SSL and MQTT over WebSocket Secure. Username: Enter the username that the client will use to access the server. Password: Enter a password for the username. Client ID: Enter a client ID. The client identifier is sent to the server when the client connects to it.Clean session: Controls the behavior at connection and disconnection time. When selected, the state information is discarded at connect and disconnect.HTTP proxy: A URL with a maximum length of 255 bytes. You can leave the field empty if you don't want to use an HTTP proxy. HTTPS proxy: A URL with a maximum length of 255 bytes. You can leave the field empty if you don't want to use an HTTPS proxy.Keep alive interval: Enables the client to detect when the server is no longer available without having to wait for the long TCP/IP timeout.Timeout: The time interval in seconds to allow a connect to complete. Default value: 60Device topic prefix: Used in the default values for the topic in the connect message and LWT message on the MQTT client tab, and in the publication conditions on the MQTT publication tab. Reconnect automatically: Specifies whether the client should reconnect automatically after a disconnect. Connect messageSpecifies if a message should be sent out when a connection is established. Send message: Turn on to send messages. Use default: Turn off to enter your own default message. Topic: Enter the topic for the default message.Payload: Enter the content for the default message.Retain: Select to keep the state of client on this TopicQoS: Change the QoS layer for the packet flow.Last Will and Testament messageThe Last Will Testament (LWT) lets a client provide a testament along with its credentials when connecting to the broker. If the client disconnects ungracefully at some point later (maybe because his power source died), it can let the broker deliver a message to other clients. This LWT message has the same form as an ordinary message and gets routed via the same mechanics.Send message: Turn on to send messages.Use default: Turn off to enter your

## The web interface

own default message.**Topic**: Enter the topic for the default message.**Payload**: Enter the content for the default message.**Retain**: Select to keep the state of client on this **TopicQoS**: Change the QoS layer for the packet flow.

#### **MQTT** publication

Use default topic prefix: Select to use the default topic prefix, that is defined in the device topic prefix in the MQTT client tab.Include topic name: Select to include the topic that describes the condition in the MQTT topic.Include topic namespaces: Select to include ONVIF topic namespaces in the MQTT topic.Include serial number: Select to include the device's serial number in

the MQTT payload. **Add condition**: Click to add a condition.**Retain**: Defines which MQTT messages are sent as retained.

- None: Send all messages as non-retained.
- Property: Send only stateful messages as retained.
- All: Send both stateful and stateless messages as retained.

QoS: Select the desired level for the MQTT publication.

#### **MQTT** subscriptions

#### +

Add subscription: Click to add a new MQTT subscription.Subscription filter: Enter the MQTT topic that you want to subscribe to.Use device topic prefix: Add the subscription filter as prefix to the MQTT topic.Subscription type:

- Stateless: Select to convert MQTT messages into a stateless message.
- Stateful: Select to convert MQTT messages into a condition. The payload is used as the state.

QoS: Select the desired level for the MQTT subscription.

#### MQTT overlays

#### Note

Connect to an MQTT broker before you add MQTT overlay modifiers.

#### 4

Add overlay modifier: Click to add a new overlay modifier. Topic filter: Add the MQTT topic that contains the data you want to show in the overlay. Data field: Specify the key for the message payload that you want to show in the overlay, assuming the message is in JSON format.

Modifier: Use the resulting modifier when you create the overlay.

- Modifiers that start with **#XMP** show all of the data received from the topic.
- Modifiers that start with **#XMD** show the data specified in the data field.

#### Storage

#### Network storage

Ignore: Turn on to ignore network storage. Add network storage: Click to add a network share where you can save recordings.
 Address: Enter the IP address or host name of the host server, typically a NAS (network-attached storage). We recommend you to configure the host to use a fixed IP address (not DHCP since a dynamic IP address can change) or

- that you use DNS. Windows SMB/CIFS names are not supported.
  Network share: Enter the name of the shared location on the host server. Several Axis devices can use the same network share since each device gets its own folder.
- User: If the server requires a login, enter the username. To log in to a specific domain server, type DOMAIN\username.
- **Password**: If the server requires a login, enter the password.
- SMB version: Select the SMB storage protocol version to connect to the NAS. If you select Auto, the device tries to negotiate one of the secure versions SMB: 3.02, 3.0, or 2.1. Select 1.0 or 2.0 to connect to older NAS that don't support higher versions. You can read more about SMB support in Axis devices *here*.
- Add share without testing: Select to add the network share even if an error is discovered during the connection test. The error can be, for example, that you didn't enter a password even though the server requires one.

## The web interface

**Remove network storage:** Click to unmount, unbind, and remove the connection to the network share. This removes all settings for the network share.**Unbind:** Click to unbind and disconnect the network share.

Bind: Click to bind and connect the network share.Unmount: Click to unmount the network share.

**Mount:** Click to mount the network share. Write protect: Turn on to stop writing to the network share and protect recordings from being removed. You can't format a write-protected network share. Retention time: Select how long to keep recordings, to limit the amount of old recordings, or to comply with regulations regarding data storage. If the network storage becomes full, old recordings are removed before the selected time period passes. Tools

- Test connection: Test the connection to the network share.
- Format: Format the network share, for example, when you need to quickly erase all data. CIFS is the available file system option.

Use tool: Click to activate the selected tool.

#### Onboard storage

#### Important

Risk of data loss and corrupted recordings. Do not remove the SD card while the device is running. Unmount the SD card before you remove it.

Unmount: Click to safely remove the SD card.Write protect: Turn on to stop writing to the SD card and protect recordings from being removed. You can't format a write-protected SD card.Autoformat: Turn on to automatically format a newly inserted SD card. It formats the file system into ext4.Ignore: Turn on to stop storing recordings on the SD card. When you ignore the SD card, the device no longer recognizes that the card exists. The setting is only available for administrators.Retention time: Select how long to keep recordings, to limit the amount of old recordings, or to comply with regulations regarding data storage. If the SD card becomes full, old recordings are removed before the selected time period has passed. Tools

- Check: Check for errors on the SD card. This only works for the ext4 file system.
  - Repair: Repair errors in the ext4 file system. To repair an SD card with the VFAT file system, eject the SD card, insert it in a computer, and perform a disk repair.
  - Format: Format the SD card, for example, when you need to change the file system or quickly erase all data. VFAT
    and ext4 are the two available file system options. The recommended format is ext4, due to its resilience against
    data loss if the card is ejected or if there is an abrupt power loss. However, you need a third-party ext4 driver or
    application to access the file system from Windows<sup>®</sup>.
- Encrypt: Use this tool to format the SD card and enable encryption. Encrypt deletes all data stored on the SD card. After using Encrypt, the data that's stored on the SD card is protected using encryption.
- Decrypt: Use this tool to format the SD card without encryption. Decrypt deletes all data stored on the SD card. After using Decrypt, the data that's stored on the SD card is not protected using encryption.
- Change password: Change the password required to encrypt the SD card.

Use tool: Click to activate the selected tool.

**Wear trigger**: Set a value for the SD card wear level at which you want to trigger an action. The wear level ranges from 0–200%. A new SD card that has never been used has a wear level of 0%. A wear level of 100% indicates that the SD card is close to its expected lifetime. When the wear-level reaches 200%, there is a high risk of the SD card malfunctioning. We recommend setting the wear trigger between 80–90%. This gives you time to download any recordings as well as replace the SD card in time before it potentially wears out. The wear trigger allows you to set up an event and get a notification when the wear level reaches your set value.

#### Stream profiles

A stream profile is a group of settings that affect the video stream. You can use stream profiles in different situations, for example, when you create events and use rules to record.

## The web interface

+
Add stream profile: Click to create a new stream profile.Preview: A preview of the video stream with the stream
profile settings you select. The preview updates when you change the settings on the page. If your device has different
view areas, you can change the view area in the drop-down in the bottom left corner of the image. Name: Add a name for
your profile.Description: Add a description of your profile.Video codec: Select the video codec that should apply for the
profile.Resolution: See for a description of this setting.Frame rate: See for a description of this setting.Compression: See for
a description of this setting.Zipstream i: See for a description of this setting.Optimize for storage : See for a
description of this setting.Dynamic FPS : See for a description of this setting.Dynamic GOP : See for a description
of this setting. <b>Mirror</b> : See for a description of this setting. <b>GOP length</b> : See for a description of this setting. <b>Bitrate</b>
control: See for a description of this setting.Include overlays: Select what type of overlays to include. See for information about
how to add overlays.Include audio : See for a description of this setting.

#### ONVIF

#### **ONVIF** accounts

ONVIF (Open Network Video Interface Forum) is a global interface standard that makes it easier for end-users, integrators, consultants, and manufacturers to take advantage of the possibilities offered by network video technology. ONVIF enables interoperability between different vendor products, increased flexibility, reduced cost and future-proof systems.

When you create an ONVIF account, you automatically enable ONVIF communication. Use the account name and password for all ONVIF communication with the device. For more information see the Axis Developer Community at axis.com.

+Add accounts: Click to add a new ONVIF account. Account: Enter a unique account name. New password: Enter a password for the account. Passwords must be 1 to 64 characters long. Only ASCII printable characters (code 32 to 126) are allowed in the password, for example, letters, numbers, punctuation, and some symbols. Repeat password: Enter the same password again. Role: · Administrator: Has full access to all settings. Administrators can also add, update, and remove other accounts.

- - Operator: Has access to all settings except: All System settings.

    - Adding apps.
  - Media account: Allows access to the video stream only.

The context menu contains: Update account: Edit the account properties. Delete account: Delete the account. You can't delete the root account.

#### **ONVIF** media profiles

An ONVIF media profile consists of a set of configurations that you can use to change media stream settings. You can create new profiles with your own set of configurations or use preconfigured profiles for a quick setup.

## ╋


Add media profile: Click to add a new ONVIF media profile.Profile name: Add a name for the media profile.Video source: Select the video source for your configuration.

- Select configuration: Select a user-defined configuration from the list. The configurations in the drop-down list correspond to the device's video channels, including multiviews, view areas and virtual channels. Video encoder: Select the video encoding format for your configuration.
  - Select configuration: Select a user-defined configuration from the list and adjust the encoding settings. The configurations in the drop-down list act as identifiers/names of the video encoder configuration. Select user 0 to 15 to apply your own settings, or select one of the default users if you want to use predefined settings for a specific encoding format.

#### Note

Enable audio in the device to get the option to select an audio source and audio encoder configuration.

# The web interface



### Analytics metadata

#### Metadata producers

Lists the apps that stream metadata and the channels they use.

**Producer**: The app that produces the metadata. Below the app is a list of the types of metadata the app streams from the device.**Channel**: The channel that the app uses. Select to enable the metadata stream. Deselect for compatibility or resource management reasons.

### Detectors

#### Camera tampering

The camera tampering detector generates an alarm when the scene changes, for example, when the lens is covered, sprayed or severely put out of focus, and the time in **Trigger delay** has passed. The tampering detector only activates when the camera has not moved for at least 10 seconds. During this period, the detector sets up a scene model to use as a comparison to detect tampering in current images. For the scene model to be set up properly, make sure that the camera is in focus, the lighting conditions are correct, and the camera doesn't point at a scene that lacks contours, for example, a blank wall. Camera tampering can be used as a condition to trigger actions.

**Trigger delay:** Enter the minimum time that the tampering conditions must be active before the alarm triggers. This can help prevent false alarms for known conditions that affect the image.**Trigger on dark images:** It is very difficult to generate alarms when the camera lens is sprayed, since it is impossible to distinguish that event from other situations where the image turns dark in a similar way, for example, when the lighting conditions change. Turn on this parameter to generate alarms for all cases where the image turns dark. When it's turned off, the device doesn't generate any alarm when the image turns dark. Note

For detection of tampering attempts in static and non-crowded scenes.

Audio detection

## The web interface

These settings are available for each audio input.**Sound level**: Adjust the sound level to a value from 0-100, where 0 is the most sensitive and 100 the least sensitive. Use the activity indicator as a guide when you set the sound level. When you create events, you can use the sound level as a condition. You can choose to trigger an action if the sound level rises above, falls below or passes the set value.

#### Shock detection

Shock detector: Turn on to generate an alarm if the device is hit by an object or if it is tampered with. Sensitivity level: Move the slider to adjust the sensitivity level at which the device should generate an alarm. A low value means that the device only generates an alarm if the hit is powerful. A high value means that the device generates an alarm even with mild tampering.

#### Accessories

#### I/O ports

Use digital input to connect external devices that can toggle between an open and closed circuit, for example, PIR sensors, door or window contacts, and glass break detectors.

Use digital output to connect external devices such as relays and LEDs. You can activate connected devices through the VAPIX® Application Programming Interface or the web interface.

PortName: Edit the text to rename the port.Direction: $$ indicates that the port is an input port. $$ indicates that it's an
output port. If the port is configurable, you can click the icons to change between input and output.Normal state: Click for
open circuit, and for closed circuit. <b>Current state</b> : Shows the current state of the port. The input or output is activated when the current state is different from the normal state. An input on the device has an open circuit when it's disconnected or when there is a voltage above 1 V DC. Note
During restart, the output circuit is open. When the restart is complete, the circuit goes back to the normal position. If you change any settings on this page, the output circuits go back to their normal positions regardless of any active triggers.
Supervised : Turn on to make it possible to detect and trigger actions if someone tampers with the connection to digital I/O devices. In addition to detecting if an input is open or closed, you can also detect if someone has tampered with it (that is, cut or shorted). To supervise the connection requires additional hardware (end-of-line resistors) in the external I/O loop.

#### Edge-to-edge

Audio pairing allows you to use a compatible Axis network speaker as if it's part of the main device. Once paired, the network speaker acts as an audio out device where you can play audio clips and transmit sound.

#### Important

For this feature to work with a video management software (VMS), you must first pair the device with the speaker, then add the device to your VMS.

Set a 'Wait between actions (hh:mm:ss)' limit in the event rule when you use a network paired audio device in an event rule with 'Audio detection' as condition and 'Play audio clip' as action. This will help you avoid a looping detection if the capturing microphone picks up audio from the speaker.

Audio pairingAddress: Enter the host name or IP address of the network speaker.Username: Enter username.Password: Enter password for the user.Speaker pairing: Select to pair a network speaker.Clear fields: Click to clear all fields.Connect: Click to establish connection to the speaker.

PTZ pairing allows you to pair a radar with a PTZ camera to use autotracking. Radar PTZ autotracking makes the PTZ camera track objects based on information from the radar about the objects' positions.

## The web interface

PTZ pairingAddress: Enter host name or IP address of the PTZ camera.Username: Enter the username of the PTZ camera.Password: Enter the password for the PTZ camera.Clear fields: Click to clear all fields.Connect: Click to establish connection to the PTZ camera.Configure radar autotracking: Click to open and configure autotracking. You can also go to Radar > Radar PTZ autotracking to configure.

#### Logs

Reports and logs

#### Reports

- View the device server report: View information about the product status in a pop-up window. The Access Log is automatically included in the Server Report.
  - **Download the device server report**: It creates a .zip file that contains a complete server report text file in UTF-8 format, as well as a snapshot of the current live view image. Always include the server report .zip file when you contact support.
- **Download the crash report**: Download an archive with detailed information about the server's status. The crash report contains information that is in the server report as well as detailed debug information. This report might contain sensitive information such as network traces. It can take several minutes to generate the report.

#### Logs

- View the system log: Click to show information about system events such as device startup, warnings, and critical messages.
- View the access log: Click to show all failed attempts to access the device, for example, when a wrong login password is used.

#### Network trace

#### Important

A network trace file might contain sensitive information, for example certificates or passwords.

A network trace file can help you troubleshoot problems by recording activity on the network. Trace time: Select the duration of the trace in seconds or minutes, and click Download.

#### Remote system log

Syslog is a standard for message logging. It allows separation of the software that generates messages, the system that stores them, and the software that reports and analyzes them. Each message is labeled with a facility code, which indicates the software type generating the message, and assigned a severity level.

Server: Click to add a new server.Host: Enter the hostname or IP address of the server.Format: Select which syslog message format to use.

- Axis
- RFC 3164
- RFC 5424

**Protocol**: Select the protocol to use:

- UDP (Default port is 514)
- TCP (Default port is 601)
- TLS (Default port is 6514)

**Port:** Edit the port number to use a different port.**Severity**: Select which messages to send when triggered.**CA certificate set**: See the current settings or add a certificate.

#### Plain config

Plain config is for advanced users with experience of Axis device configuration. Most parameters can be set and edited from this page.

### Maintenance

**Restart:** Restart the device. This does not affect any of the current settings. Running applications restart automatically.**Restore:** Return *most* settings to the factory default values. Afterwards you must reconfigure the device and apps, reinstall any apps that didn't come preinstalled, and recreate any events and presets. Important

The only settings saved after restore are:

- Boot protocol (DHCP or static)
- Static IP address
- Default router
- Subnet mask
- 802.1X settings
- 03C settings
- DNS server IP address

Factory default: Return *all* settings to the factory default values. Afterwards you must reset the IP address to make the device accessible.

Note

All Axis device software is digitally signed to ensure that you only install verified software on your device. This further increases the overall minimum cybersecurity level of Axis devices. For more information, see the white paper "Axis Edge Vault" at *axis.com*.

**AXIS OS upgrade:** Upgrade to a new AXIS OS version. New releases can contain improved functionality, bug fixes, and completely new features. We recommend you to always use the latest AXIS OS release. To download the latest release, go to *axis.com/support*. When you upgrade, you can choose between three options:

- Standard upgrade: Upgrade to the new AXIS OS version.
- Factory default: Upgrade and return all settings to the factory default values. When you choose this option, you can't revert to the previous AXIS OS version after the upgrade.
- Autorollback: Upgrade and confirm the upgrade within the set time. If you don't confirm, the device reverts to the previous AXIS OS version.

AXIS OS rollback: Revert to the previously installed AXIS OS version.

### Learn more

### Learn more

### Long-distance connections

This product supports fiber-optic cable installations through a media converter. Fiber-optic cable installations offer a number of benefits such as:

- Long-distance connection
- High speed
- Long lifetime
- Large capacity of data transmission
- Electromagnetic interference immunity

Find out more about fiber-optic cable installations in the white paper "Long distance surveillance - Fiber-optic communication in network video" at *axis.com/learning/white-papers*.

For information about how to install the media converter see the Installation Guide for this product.

## Remote focus and zoom

The remote focus and zoom functionality allows you to make focus and zoom adjustments to your camera from a computer. It is a convenient way to ensure that the scene's focus, viewing angle and resolution are optimized without having to visit the camera's installation location.

### Privacy masks

A privacy mask is a user-defined area that covers a part of the monitored area. In the video stream, privacy masks appear either as blocks of solid color or with a mosaic pattern.

You'll see the privacy mask on all snapshots, recorded video, and live streams.

You can use the VAPIX® application programming interface (API) to hide the privacy masks.

#### Important

If you use multiple privacy masks it may affect the product's performance.

You can create several privacy masks. Each mask can have 3 to 10 anchor points.

## **Overlays**

Overlays are superimposed over the video stream. They are used to provide extra information during recordings, such as a timestamp, or during product installation and configuration. You can add either text or an image.

The video streaming indicator is another type of overlay. It shows you that the live view video stream is live.

### Streaming and storage

#### Video compression formats

Decide which compression method to use based on your viewing requirements, and on the properties of your network. The available options are:

Motion JPEG

## Learn more

#### Note

To ensure support for the Opus audio codec, the Motion JPEG stream is always sent over RTP.

Motion JPEG, or MJPEG, is a digital video sequence that is made up of a series of individual JPEG images. These images are then displayed and updated at a rate sufficient to create a stream that shows constantly updated motion. For the viewer to perceive motion video the rate must be at least 16 image frames per second. Full motion video is perceived at 30 (NTSC) or 25 (PAL) frames per second.

The Motion JPEG stream uses considerable amounts of bandwidth, but provides excellent image quality and access to every image contained in the stream.

#### H.264 or MPEG-4 Part 10/AVC

#### Note

H.264 is a licensed technology. The Axis product includes one H.264 viewing client license. To install additional unlicensed copies of the client is prohibited. To purchase additional licenses, contact your Axis reseller.

H.264 can, without compromising image quality, reduce the size of a digital video file by more than 80% compared to the Motion JPEG format and by as much as 50% compared to older MPEG formats. This means that less network bandwidth and storage space are required for a video file. Or seen another way, higher video quality can be achieved for a given bitrate.

#### H.265 or MPEG-H Part 2/HEVC

H.265 can, without compromising image quality, reduce the size of a digital video file by more than 25% compared to H.264.

#### Note

- H.265 is licensed technology. The Axis product includes one H.265 viewing client license. Installing additional unlicensed copies of the client is prohibited. To purchase additional licenses, contact your Axis reseller.
- Most web browsers don't support H.265 decoding and because of this the camera doesn't support it in its web interface. Instead you can use a video management system or application supporting H.265 decoding.

#### How do Image, Stream, and Stream profile settings relate to each other?

The Image tab contains camera settings that affect all video streams from the product. If you change something in this tab, it immediately affects all video streams and recordings.

The **Stream** tab contains settings for video streams. You get these settings if you request a video stream from the product and don't specify for example resolution, or frame rate. When you change the settings in the **Stream** tab, it doesn't affect ongoing streams, but it will take effect when you start a new stream.

The **Stream profiles** settings override the settings from the **Stream** tab. If you request a stream with a specific stream profile, the stream contains the settings of that profile. If you request a stream without specifying a stream profile, or request a stream profile that doesn't exist in the product, the stream contains the settings from the **Stream** tab.


#### Bitrate control

Bitrate control helps you to manage the bandwidth consumption of your video stream.

#### Variable bitrate (VBR)


Variable bitrate allows the bandwidth consumption to vary depending on the level of activity in the scene. The more activity, the more bandwidth you need. With variable bitrate you are guaranteed constant image quality, but you need to make sure you have storage margins.

### Learn more



#### Maximum bitrate (MBR)

Maximum bitrate lets you set a target bitrate to handle bitrate limitations in your system. You might see a decline in image quality or frame rate as the instantaneous bitrate is kept below the specified target bitrate. You can choose to prioritize either image quality or frame rate. We recommend that you configure the target bitrate to a higher value than the expected bitrate. This gives you a margin in case there is a high level of activity in the scene.




1 Target bitrate

#### Average bitrate (ABR)

With average bitrate, the bitrate is automatically adjusted over a longer period of time. This is so you can meet the specified target and provide the best video quality based on your available storage. Bitrate is higher in scenes with a lot of activity, compared to static scenes. You are more likely to get better image quality when in scenes with a lot of activity if you use the average bitrate option. You can define the total storage required to store the video stream for a specified amount of time (retention time) when image quality is adjusted to meet the specified target bitrate. Specify the average bitrate settings in one of the following ways:

- To calculate the estimated storage need, set the target bitrate and the retention time.
- To calculate the average bitrate, based on available storage and required retention time, use the target bitrate calculator.


### Learn more



1 Target bitrate

2 Actual average bitrate

You can also turn on maximum bitrate and specify a target bitrate within the average bitrate option.



- 1 Target bitrate
- 2 Actual average bitrate

## Cybersecurity

### Axis Edge Vault

Axis Edge Vault provides a hardware-based cybersecurity platform that safeguards the Axis device. It offers features to guarantee the device's identity and integrity and to protect your sensitive information from unauthorized access. It builds on a strong foundation of cryptographic computing modules (secure element and TPM) and SoC security (TEE and secure boot), combined with expertise in edge device security.

### Signed OS

Signed OS is implemented by the software vendor signing the AXIS OS image with a private key. When the signature is attached to the operating system, the device will validate the software before installing it. If the device detects that the integrity of the software is compromised, the AXIS OS upgrade will be rejected.

#### Secure boot

Secure boot is a boot process that consists of an unbroken chain of cryptographically validated software, starting in immutable memory (boot ROM). Being based on the use of signed OS, secure boot ensures that a device can boot only with authorized software.

### Learn more

#### Secure keystore

A tamper-protected environment for the protection of private keys and secure execution of cryptographic operations. It prevents unauthorized access and malicious extraction in the event of a security breach. Depending on security requirements, an Axis device can have either one or multiple hardware-based cryptographic computing modules, which provide a hardware-protected secure keystore. Depending on security requirements, an Axis device can have either one or multiple hardware-based cryptographic computing modules, like a TPM 2.0 (Trusted Platform Module) or a secure element, and/or a TEE (Trusted Execution Environment), which provide a hardware-protected secure keystore. Furthermore, selected Axis products feature a FIPS 140-2 Level 2-certified secure keystore.

#### Axis device ID

Being able to verify the origin of the device is key to establishing trust in the device identity. During production, devices with Axis Edge Vault are assigned a unique, factory-provisioned, and IEEE 802.1AR-compliant Axis device ID certificate. This works like a passport to prove the origin of the device. The device ID is securely and permanently stored in the secure keystore as a certificate signed by Axis root certificate. The device ID can be leveraged by the customer's IT infrastructure for automated secure device onboarding and secure device identification

#### Signed video

Signed video ensures that video evidence can be verified as untampered without proving the chain of custody of the video file. Each camera uses its unique video signing key, which is securely stored in the secure keystore, to add a signature into the video stream. When the video is played, the file player shows whether the video is intact. Signed video makes it possible to trace the video back to the camera origin and verifies that the video has not been tampered with after it left the camera.

#### Encrypted file system

The secure keystore prevents the malicious exfiltration of information and prevents configuration tampering by enforcing strong encryption upon the file system. This ensures no data stored in the file system can be extracted or tampered with when the device is not in use, unauthenticated access to the device is achieved and/or the Axis device is stolen. During the secure boot process, the read-write filesystem is decrypted and can be mounted and used by the Axis device.

To learn more about the cybersecurity features in Axis devices, go to axis.com/learning/white-papers and search for cybersecurity.

#### Axis security notification service

Axis provides a notification service with information about vulnerability and other security related matters for Axis devices. To receive notifications, you can subscribe at *axis.com/security-notification-service*.

#### Vulnerability management

To minimize customers' risk of exposure, Axis, as a **Common Vulnerability and Exposures (CVE) numbering authority (CNA)**, follows industry standards to manage and respond to discovered vulnerabilities in our devices, software, and services. For more information about Axis vulnerability management policy, how to report vulnerabilities, already disclosed vulnerabilities, and corresponding security advisories, see *axis.com/vulnerability-management*.


#### Secure operation of Axis devices

Axis devices with factory default settings are pre-configured with secure default protection mechanisms. We recommend using more security configuration when installing the device. To find out more about Axis hardening guides and other cyber security related documentation, go to *axis.com/support/cybersecurity/resources*.

# Specifications


# Specifications

## **Product** overview



- 1 Weathershield
- 2 Window
- 3 Radar
- 4 Light sensor
- 5 IR illumination LED
- 6 Optical unit
- 7 Cable cover
- 8 Intrusion alarm sensor
- 9 Safety wire
- 10 Intrusion alarm magnet

# Specifications



- 11 I/O connector
- 12 RS485/RS422 connector
- 13 Power connector
- 14 Network connector (PoE)
- 15 microSD card slot
- 16 Audio out
- 17 Audio in
- 18 Status LED
- 19 Control button
- 20 Cable gasket M20 2x

### **LED** indicators

#### Note

- The Status LED can be configured to flash while an event is active.
- The LEDs turn off when you close the casing.

Status LED	Indication	
Unlit	Connection and normal operation.	
Green	Shows steady green for 10 seconds for normal operation after startup completed.	
Amber	Steady during startup. Flashes during device software upgrade or reset to factory default.	
Amber/Red	Flashes amber/red if network connection is unavailable or lost.	
Red	Device software upgrade failure.	

## SD card slot

This device supports microSD/microSDHC/microSDXC cards.

For SD card recommendations, see axis.com.

## Specifications

mss mss microSD, microSDHC, and microSDXC Logos are trademarks of SD-3C LLC. microSD, microSDHC, microSDXC are trademarks or registered trademarks of SD-3C, LLC in the United States, other countries or both.

### **Buttons**

#### **Control button**

The control button is used for:

- Resetting the product to factory default settings. See .
- Connecting to a one-click cloud connection (03C) service over the internet. To connect, press and hold the button for about 3 seconds until the status LED flashes green.

#### Intrusion alarm switch

Use the intrusion alarm switch to get a notification when someone opens the device's housing. Create a rule to make the device perform an action when the switch is activated. See .

### Connectors

#### Network connector

RJ45 Ethernet connector with Power over Ethernet Plus (PoE+).

#### Audio connector

- Audio in 3.5 mm input for a mono microphone, or a line-in mono signal (left channel is used from a stereo signal).
- Audio in 3.5 mm input for a digital microphone, an analog mono microphone, or a line-in mono signal (left channel is used from a stereo signal).
- Audio out 3.5 mm output for audio (line level) that can be connected to a public address (PA) system or an active speaker with a built-in amplifier. A stereo connector must be used for audio out.



#### Audio input

1 Tip	2 Ring	3 Sleeve
Unbalanced microphone (with or without electret power) or line-in	Electret power if selected	Ground
Balanced microphone (with or without phantom power) or line-in, "hot" signal	Balanced microphone (with or without phantom power) or line-in, "cold" signal	Ground
Digital signal	Ring power if selected	Ground

#### Audio output

1 Tip	2 Ring	3 Sleeve
Channel 1, unbalanced line, mono	Channel 1, unbalanced line, mono	Ground

# Specifications

#### I/O connector


Use the I/O connector with external devices in combination with, for example, motion detection, event triggering, and alarm notifications. In addition to the 0 V DC reference point and power (12 V DC output), the I/O connector provides the interface to:

**Digital input** – For connecting devices that can toggle between an open and closed circuit, for example PIR sensors, door/window contacts, and glass break detectors.

Supervised input - Enables possibility to detect tampering on a digital input.


**Digital output –** For connecting external devices such as relays and LEDs. Connected devices can be activated by the VAPIX® Application Programming Interface, through an event or from the device's web interface.

6-pin terminal block



Function	Pin	Notes	Specifications
DC ground	1		0 V DC
DC output	2	Can be used to power auxiliary equipment. Note: This pin can only be used as power out.	12 V DC Max load = 50 mA
Configurable (Input or Output)	3–6	Digital input or Supervised input – Connect to pin 1 to activate, or leave floating (unconnected) to deactivate. To use supervised input, install end-of-line resistors. See connection diagram for information about how to connect the resistors.	0 to max 30 V DC
active, and floating (unconnected) when inactive. If used wit		Digital output – Internally connected to pin 1 (DC ground) when active, and floating (unconnected) when inactive. If used with an inductive load, e.g., a relay, connect a diode in parallel with the load, to protect against voltage transients.	0 to max 30 V DC, open drain, 100 mA

Example:




- 1 DC ground
- 2 DC output 12 V, max 50 mA
- 3 *I/O configured as supervised input*
- 4 I/O configured as output
- 5 Configurable I/O
- 6 Configurable I/O

# Specifications

#### Power connector

2-pin terminal block for DC power input. Use a Safety Extra Low Voltage (SELV) compliant limited power source (LPS) with either a rated output power limited to  $\leq$  100 W or a rated output current limited to  $\leq$  5 A.




### RS485/RS422 connector

Two 2-pin terminal blocks for RS485/RS422 serial interface.

The serial port can be configured to support:

- Two-wire RS485 half duplex
- Four-wire RS485 full duplex
- Two-wire RS422 simplex
- Four-wire RS422 full duplex point to point communication



Function	Notes
RS485/RS422 TX(A)	TX pair for RS422 and 4-wire RS485
RS485/RS422 TX(B)	
RS485A alt RS485/422 RX(A)	RX pair for all modes (combined RX/TX for 2-wire RS485)
RS485B alt RS485/422 RX(B)	

## Clean your device

# Clean your device

You can clean your device with lukewarm water.

### NOTICE

- Harsh chemicals can damage the device. Don't use chemicals such as window cleaner or acetone to clean your device.
- Avoid cleaning in direct sunlight or elevated temperatures, since this can cause stains.
- 1. Use a can of compressed air to remove dust and loose dirt from the device.
- 2. If necessary, clean the device with a soft microfiber cloth dampened with lukewarm water.
- 3. To avoid stains, dry the device with a clean, nonabrasive cloth.

## Troubleshooting

### Troubleshooting

## Reset to factory default settings

#### WARNING

A Possibly hazardous optical radiation is emitted from this product. It can be harmful to the eyes. Don't stare at the operating lamp.

#### Important

Reset to factory default should be used with caution. A reset to factory default resets all settings, including the IP address, to the factory default values.

To reset the product to the factory default settings:

- 1. Disconnect power from the product.
- 2. Press and hold the control button while reconnecting power. See .
- 3. Keep the control button pressed for 15–30 seconds until the status LED indicator flashes amber.
- 4. Release the control button. The process is complete when the status LED indicator turns green. The product has been reset to the factory default settings. If no DHCP server is available on the network, the default IP address is 192.168.0.90.
- 5. Use the installation and management software tools to assign an IP address, set the password, and access the device.

The installation and management software tools are available from the support pages on axis.com/support.

You can also reset parameters to factory default through the device's web interface. Go to Maintenance > Factory default and click Default.

## **AXIS OS options**

Axis offers device software management according to either the active track or the long-term support (LTS) tracks. Being on the active track means continuously getting access to all the latest product features, while the LTS tracks provide a fixed platform with periodic releases focused mainly on bug fixes and security updates.

Using AXIS OS from the active track is recommended if you want to access the newest features, or if you use Axis end-to-end system offerings. The LTS tracks are recommended if you use third-party integrations, which are not continuously validated against the latest active track. With LTS, the products can maintain cybersecurity without introducing any significant functional changes or affecting any existing integrations. For more detailed information about Axis device software strategy, go to *axis.com/support/device-software*.

## Check the current AXIS OS version

AXIS OS determines the functionality of our devices. When you troubleshoot a problem, we recommend that you to start by checking the current AXIS OS version. The latest version might contain a correction that fixes your particular problem.

To check the current AXIS OS version:

- 1. Go to the device's web interface > Status.
- 2. Under Device info, see the AXIS OS version.

# Troubleshooting

### **Upgrade AXIS OS**

#### Important

- Preconfigured and customized settings are saved when you upgrade the device software (provided that the features are available in the new AXIS OS) although this is not guaranteed by Axis Communications AB.
- Make sure the device remains connected to the power source throughout the upgrade process.

#### Note

When you upgrade the device with the latest AXIS OS version in the active track, the product receives the latest functionality available. Always read the upgrade instructions and release notes available with each new release before you upgrade. To find the latest AXIS OS version and the release notes, go to *axis.com/support/device-software*.

- 1. Download the AXIS OS file to your computer, available free of charge at axis.com/support/device-software.
- 2. Log in to the device as an administrator.
- 3. Go to Maintenance > AXIS OS upgrade and click Upgrade.

When the upgrade has finished, the product restarts automatically.

### Technical issues, clues, and solutions

If you can't find what you're looking for here, try the troubleshooting section at axis.com/support.

Problems upgrading AXIS OS		
AXIS OS upgrade failure	If the upgrade fails, the device reloads the previous version. The most common reason is that the wrong AXIS OS file has been uploaded. Check that the name of the AXIS OS file corresponds to your device and try again.	
Problems after AXIS OS upgrade	If you experience problems after the upgrade, roll back to the previously installed version from the Maintenance page.	
Problems setting the IP add	ress	
The device is located on a different subnet	If the IP address intended for the device and the IP address of the computer used to access the device are located on different subnets, you cannot set the IP address. Contact your network administrator to obtain an IP address.	
The IP address is being used by another device	<ul> <li>Disconnect the Axis device from the network. Run the ping command (in a Command/DOS window type ping and the IP address of the device):</li> <li>If you receive: Reply from <ip address="">: bytes=32; time=10 this means that the IP address may already be in use by another device on the network Obtain a new IP address from the network administrator and reinstall the device.</ip></li> <li>If you receive: Request timed out, this means that the IP address is available for use with the Axis device. Check all cabling and reinstall the device.</li> </ul>	
Possible IP address conflict with another device on the same subnet	The static IP address in the Axis device is used before the DHCP server sets a dynamic address. This means that if the same default static IP address is also used by another device, there may be problems accessing the device.	
The device can't be accessed	d from a browser	
Can't log in	When HTTPS is enabled, ensure that the correct protocol (HTTP or HTTPS) is used when attempting	

to log in. You may need to manually type http or https in the browser's address field. If the password for the root account is lost, the device must be reset to the factory default settings. See .

## Troubleshooting

The IP address has been changed by DHCP	IP addresses obtained from a DHCP server are dynamic and may change. If the IP address has been changed, use AXIS IP Utility or AXIS Device Manager to locate the device on the network. Identify the device using its model or serial number, or by the DNS name (if the name has been configured).If required, a static IP address can be assigned manually. For instructions, go to <i>axis.com/support</i> .
Certificate error when using IEEE 802.1X	For authentication to work properly, the date and time settings in the Axis device must be synchronized with an NTP server. Go to <b>System &gt; Date and time</b> .

#### The device is accessible locally but not externally

To access the device externally, we recommend you to use one of the following applications for Windows®:

• AXIS Camera Station 5: 30-day trial version free of charge, ideal for small to mid-size systems.

• AXIS Camera Station Pro: 90-day trial version free of charge, ideal for small to mid-size systems.

For instructions and download, go to axis.com/vms.

#### Can't connect over port 8883 with MQTT over SSL

The firewall blocks traffic using port 8883 as it's deemed insecure. Problems with overlays whe	<ul> <li>In some cases the server/broker might not provide a specific port for MQTT communication. It may still be possible to use MQTT over a port normally used for HTTP/HTTPS traffic.</li> <li>If the server/broker supports WebSocket/WebSocket Secure (WS/WSS), typically on port 443, use this protocol instead. Check with the server/broker provider to see if WS/WSS is supported and which port and basepath to use.</li> <li>If the server/broker supports ALPN, the use of MQTT can be negotiated over an open port, such as 443. Check with your server/broker provider to see if ALPN is supported and which ALPN protocol and port to use.</li> </ul>
The license plate overlay is not available in the device's onscreen controls	If the license plate overlay isn't available in the device's onscreen controls after you have installed AXIS License Plate Verifier, try to restart the device.Go to the Maintenance page and click Restart.
Speed is missing in the	If the speed is missing in the license plate overlay after you have installed AXIS License Plate

license plate overlay in the device's onscreen controls set the installation height in the device, go to Radar > Settings > General > Mounting height.

## Performance considerations

The following factors are the most important to consider:

• Heavy network utilization due to poor infrastructure affects the bandwidth.

## **Contact support**

If you need more help, go to axis.com/support.

User manual AXIS Q1686-DLE Radar-Video Fusion Camera © Axis Communications AB, 2024 Ver. M2.2 Date: July 2024 Part no. T10202497